



MANUAL OPERATOR HASSI MESSAOUD

			MD-XXX-09		
0	22/06/15	ISSUE	Massimo Piga		
Rev	Date	Description	Written	Controlled	Approved





SUMMARY:

1	REFERENCE DOCUMENTS	6
2	LEGEND	7
3	INTRODUCTION	8
4	DESCRIPTION OF THE CONTROL SYSTEM	9
4.1	LIST OF ITEMS DESCRIBED IN THE MANUAL	9
4.2	DESCRIPTION OF ARCHITECTURE	9
5	DESCRIPTION HMI SYSTEM	12
5.1	INTRODUCTION	12
5.2	HMI SYSTEM ARCHITECTURE	12
5.3	DESCRIPTION OF CONTROL AND VIEWING AREAS	14
5.3.1	OBJECT FOR "ANALOG SIGNALS"	14
5.3.2	OBJECT FOR B "DIGITAL SIGNALS"	16
5.3.3	C OBJECT FOR "ELECTRICAL EQUIPMENT"	17
5.3.4	OBJECT FOR "RUN COUNTER HOURS"	19
5.3.5	OBJECT FOR E "VALVES ALL OR NOTHING"	19
5.3.6	OBJECT FOR F "REGULATOR PID"	22
5.4	ALARM MANAGEMENT	26
5.4.1	CHARACTERIZING PHASE ALARMS	27
5.4.2	ACTIONS TO BE PERFORMED IN CASE OF OCCURRENCE OF AN ALARM	29
5.5	OVERVIEW SCREEN PAGES	30
5.5.1	MAIN MENU	30
5.5.2	P&ID: GAS DISCHARGE	30
5.5.3	P & ID: SYSTEM LUBRICATING OIL AND MOUTH	31
5.5.4	P & ID: AIR INSTRUMENTS	31
5.5.5	P & ID: CONTROL PAGE	32
5.5.6	P & ID: 1 st STAGE COMPRESSOR	32
5.5.7	P & ID: 2 nd STAGE COMPRESSOR	33
5.5.8	P & ID: A GEAR BOX	34
5.5.9	CONTROLLER: TURBINE	34
5.5.10	CONTROLLER: ANTISURGE CONTROL	35
5.5.11	MOS: MANUAL BYPASS LOCKS	35
5.5.12	DIAGNOSTIC	36
5.5.13	DIGITAL INPUTS TABLE	37
5.5.14	INPUT SIGNALS TABLE MCC	37
5.5.15	SIMILAR THRESHOLD	38
5.5.16	PRINT DATA LOGGING	40
5.5.17	ADMINISTRATION	42
6	FUNCTIONAL DESCRIPTION	43
6.1	INTRODUCTION	43
6.2	GAS CIRCUIT	43
6.2.1	COMPONENTS	43
6.2.2	OPERATION	44
6.3	OIL SYSTEMS	45
6.3.1	COMPONENTS	45
6.3.2	PRIOR	46
6.3.3	OPERATION	46
6.4	CIRCUIT AIR INSTRUMENTS	48
6.4.1	COMPONENTS	48
6.5	CIRCUIT COMBUSTION AIR AND BURNING	49
6.5.1	COMPONENTS	49
6.5.2	PRIOR	50
6.5.3	OPERATION	50
6.6	TURBINE CONTROL	52
6.6.1	COMPONENTS	53
6.6.2	PRIOR	53



6.6.3	OPERATION.....	55
6.6.3.1	RESET OF TRIGGERS.....	55
6.6.3.2	STARTING THE TURBINE.....	56
6.6.3.3	CONTROL AND SAFETY.....	58
6.6.3.4	STOP PLANNED.....	59
6.6.3.5	MONITORING OF MEASURES.....	59
6.6.3.5.1	TABLE STARTS.....	62
6.6.3.6	PARAMETERS CONFIGURETION CONTROL.....	62
6.7	COMPRESSOR.....	63
6.7.1	COMPONENTS.....	63
6.7.2	PRIOR.....	64
6.7.3	OPERATION.....	65
7	FUNCTIONAL DESCRIPTION AUXILIARY COMPONENTS	65
7.1	ELECTRICAL EQUIPMENT.....	65
7.1.1	AUXILIARY OIL PUMP: PMOA.....	65
7.1.1.1	MANAGEMENT MANUAL.....	65
7.1.1.2	AUTOMATIC MANAGEMENT.....	65
7.1.1.3	PRESENCE OF PRIORITY CONTROL (OVERRIDE).....	66
7.1.1.4	FAULTS.....	66
7.1.2	OIL PUMP RELIEF: PMOE.....	68
7.1.2.1	MANAGEMENT MANUAL.....	68
7.1.2.2	AUTOMATIC MANAGEMENT.....	68
7.1.2.3	PRESENCE OF PRIORITY CONTROL (OVERRIDE).....	69
7.1.2.4	FAULTS.....	69
7.1.3	OIL COOLER: EH1.....	70
7.1.3.1	MANAGEMENT MANUAL.....	70
7.1.3.2	AUTOMATIC MANAGEMENT.....	70
7.1.3.3	PRESENCE OF PRIORITY CONTROL (OVERRIDE).....	71
7.1.3.4	FAULTS.....	71
7.1.4	EXTRACTION OF OIL FUMES: OIL STEAM EXTR.....	73
7.1.4.1	MANAGEMENT MANUAL.....	73
7.1.4.2	AUTOMATIC MANAGEMENT.....	73
7.1.4.3	PRESENCE OF PRIORITY CONTROL (OVERRIDE).....	74
7.1.4.4	FAULTS.....	75
7.1.5	FAN OIL COOLER: T2AB.....	76
7.1.5.1	MANAGEMENT MANUAL OBJECT E1.....	76
7.1.5.2	AUTOMATIC MANAGEMENT OBJECT E1.....	76
7.1.5.3	PRESENCE OF PRIORITY CONTROL (OVERRIDE).....	78
7.1.5.4	MANAGEMENT MANUAL OBJECT "E1 INV".....	78
7.1.5.5	AUTOMATIC MANAGEMENT OF THE OBJECT "E1 INV".....	78
7.1.5.6	FAULTS.....	79
7.1.6	FAN OIL COOLER: T2BB.....	81
7.1.6.1	MANAGEMENT MANUAL OBJECT E2.....	81
7.1.6.2	AUTOMATIC MANAGEMENT OBJECT E2.....	81
7.1.6.3	PRESENCE OF PRIORITY CONTROL (OVERRIDE).....	83
7.1.6.4	MANAGEMENT MANUAL OBJECT "E2 INV".....	83
7.1.6.5	AUTOMATIC MANAGEMENT OF THE OBJECT "E2 INV".....	83
7.1.6.6	FAULTS.....	84
7.1.7	TURNING GEAR: VIR.....	86
7.1.7.1	MANAGEMENT MANUAL.....	86
7.1.7.2	AUTOMATIC MANAGEMENT.....	86
7.1.7.3	PRESENCE OF PRIORITY CONTROL (OVERRIDE).....	87
7.1.7.4	FAULTS.....	87
7.1.8	AIR TREATMENT SYSTEM INSTRUMENTS: DRY-COOLER.....	88
7.1.8.1	MANAGEMENT MANUAL.....	88
7.1.8.2	FAULTS.....	88
7.1.9	EXTRACTION OF SAND: S-EM1.....	90
7.1.9.1	MANAGEMENT MANUAL.....	90
7.1.9.2	AUTOMATIC MANAGEMENT.....	90
7.1.9.3	PRESENCE OF PRIORITY CONTROL (OVERRIDE).....	91
7.1.9.4	FAULTS.....	91
7.1.10	Cleaning system (PULSE JET): SQZ1.....	93
7.1.10.1	MANAGEMENT MANUAL.....	93
7.1.10.2	AUTOMATIC MANAGEMENT.....	93
7.1.10.3	PRESENCE OF PRIORITY CONTROL (OVERRIDE).....	94



7.1.10.4	FAULTS	95
7.1.11	INTERSTAGE AIR COOLER FAN EL. MOTOR	96
7.1.11.1	MANAGEMENT MANUAL	96
7.1.11.2	AUTOMATIC MANAGEMENT	96
7.1.11.3	FAULTS	97
7.1.12	COMPRESSOR SEAL/LUBE OIL MAIN & AUX EL. MOTOR	98
7.1.12.1	MANAGEMENT MANUAL	98
7.1.12.2	AUTOMATIC MANAGEMENT	98
7.1.12.3	FAULTS	99
7.1.13	COMPRESSOR SEAL/LUBE OIL EMERGENCY EL. MOTOR	100
7.1.13.1	MANAGEMENT MANUAL	100
7.1.13.2	AUTOMATIC MANAGEMENT	100
7.1.13.3	FAULTS	101
7.2	VALVES ALL OR NOTHING	102
7.2.1	STOP GAS FUEL VALVE: FGV1	102
7.2.1.1	MANAGEMENT MANUAL	102
7.2.1.2	AUTOMATIC MANAGEMENT	102
7.2.1.3	PRESENCE OF PRIORITY CONTROL (OVERRIDE)	103
7.2.1.4	FAULTS	103
7.2.2	PURGE VALVE FUEL GAS: FGV6	104
7.2.2.1	MANAGEMENT MANUAL	104
7.2.2.2	AUTOMATIC MANAGEMENT	104
7.2.2.3	PRESENCE OF PRIORITY CONTROL (OVERRIDE)	105
7.2.2.4	FAULTS	105
7.2.3	ISOLATION VALVE FUEL GAS: FGV4	106
7.2.3.1	MANAGEMENT MANUAL	106
7.2.3.2	AUTOMATIC MANAGEMENT	106
7.2.3.3	PRESENCE OF PRIORITY CONTROL (OVERRIDE)	107
7.2.3.4	FAULTS	107
7.2.4	VALVE ANTIMPOMPAGE: VBY	107
7.2.4.1	MANAGEMENT MANUAL	108
7.2.4.2	AUTOMATIC MANAGEMENT	108
7.2.4.3	PRESENCE OF PRIORITY CONTROL (OVERRIDE)	108
7.2.4.4	FAULTS	108
8	SCHEDULES	120
8.1	DISPLAY HISTORICAL DATA (HISTORIAN VIEWER)	121
8.1.1	MAIN WINDOW OF THE HISTORIAN VIEWER	121
8.1.2	VIEW TREND (TREND DISPLAY)	122
8.1.3	DISPLAY OF LEGENDS	123
8.1.4	SAVE / LOAD SETTING TRACKS	126
8.1.4.1	CSV EXPORT TO DATA	128



1 REFERENCE DOCUMENTS

ID	No.	DESCRIPTION	REV
1	MD-222-09	Diagram piping and instrumentation	6
2			
3			
8			
4			
5			
6			
7			



2 LEGEND

DCS	:	Distributed control system
ESM	:	Motor launch
FGV	:	Gas Valve
HMI	:	Operator interface (screen pages)
MOS	:	Minimum operating speed
SOV	:	Solenoid
VIR	:	Rotator



3 INTRODUCTION

The purpose of this document is to provide the central Sonatrach Hassi Messaoud operators the information needed to drive the gas turbine through the interfaces to the table UCP (group control panel) and the MCC chart (control station engines).



4 DESCRIPTION OF THE CONTROL SYSTEM

4.1 LIST OF ITEMS DESCRIBED IN THE MANUAL

The elements that are part of the control system, the operation is the subject of this manual listed below:

- UCP: Unit Control Panel;
- MCC switchboard for supplying electrical equipment and alternating voltage;
- HMI: Human-Machine Interface;
- E1, E2: UPS units for lube oil fans;

The Figure 4-1 below shows a map with the spatial arrangement of the control system tables.




Figure 4-1

4.2 DESCRIPTION OF ARCHITECTURE

The schema Figure 4-2 Architecture of the system & co Figure 4-2 illustrates the architecture of the control system.




Figure 4-2 : Control System Architecture



Referring to the Figure 4-2, Hereinafter lists the various subsystems with a brief description of the function they perform:

- **UCP**, Control panel. He understands:
 - Redundant system CPU:
 - **CPU 1**;
 - **CPU 2**;
 - Rack I / O cards for controlling the turbine:
 - **RACK / O A**;
 - Monitoring and protection system and turbine vibration generator:
 - **ENTEK A**;
 - **ENTEK B**;
 - **ENTEK C**;
 - Rack I / O cards for control of auxiliary components:
 - **RACK E/S B**;
 - HUB-SWITCH (switching node) for the interconnection of devices ETHERNET:
 - **ETHERNET**;
 - Industrial OP for historical data logging and serial communications management;
 - Security API (**Safety PLC**) for contact management from:
 - Emergency pushbuttons;
- **Interface**, Interface system between operators and the control system, consisting of the following units that communicate with the PCU via Ethernet:
 - **HMI**: Desktop that performs the human-machine interface function to act on the control system;
 - **TURBINE** Industrial OP without keyboard, with touch screen interface type for the configuration of the turbine control parameters;
 - **ENGINEER**: Laptop that performs the engineering station function, which includes among others the display client software from HISTORIAN historical data;
- Main valve of the turbine fuel (**FGV3**). This is a valve type fuel metering ("Fuel Metering"), she received the PCU a 4-20 mA signal type and interprets it as a debit reference: a high performance control system Built in the same valve modulates the opening of the valve so that the flow rate is equal to that requested by the PCU.
- Inverters for control of the oil cooler fans (**E1** and **E2**). They receive signal of 4-20mA PCU and based on this signal, modulating the speed of the powered engines.
- **MCC**, Motor Control Centre (motor control center). He understands:
 - System Remote I / O connected to the CPUs of the PCU:
 - **RACK A MCC**
 - **RACK B MCC**
 - MCC drawers **type A** characterized by:
 - Contactor controlled by a digital output of the **RACK OF MCC**;
 - Disconnect coil controlled by a digital output of the **RACK OF MCC**;
 - Feedback "switch activated" to a digital input of the **RACK OF MCC**;
 - MCC drawers **type B** characterized by:
 - Disconnect coil controlled by a digital output of the **RACK OF MCC**;
 - Feedback "switch activated" to a digital input of the **RACK OF MCC**;
 - Device for starting the understeer (**VIR**);
 - Device for the start of the backup pump (i.e. **PMOE**);



5 DESCRIPTION HMI SYSTEM

5.1 INTRODUCTION

The purpose of this chapter is to describe the structure and operation of the video interface system to the operator, also called HMI.

5.2 HMI SYSTEM ARCHITECTURE

Each screen page is divided into five sections.




Figure 5-5-1 Structure HMI



- **SECTION 1**

The upper band contains the following information:

- Names and logos of companies MESIT and Sonatrach;
- Title screen page;

- **SECTION 2**

This area contains buttons to display the different screen pages.

- **SECTION 3**

This area contains important information such as:

- State of the turbine;
- Speed;
- Temperature to the combustion chambers;
- Discharge pressure axial compressor;
- Exhaust temperatures;
- Load;
- Temperature at the chimney;
- Opening of the main valve;
- Opening the starting valve.

- **SECTION 4**

Alarm Banner. Top thereof the most recent messages are display.

- **SECTION 5**

Area that depends on the applied specific screen-page.




5.3 DESCRIPTION OF CONTROL AND VIEWING AREAS

The pages contain multiple objects with monitoring function or command. Below is provide an explanation of these objects.

5.3.1 OBJECT FOR "ANALOG SIGNALS"

<p>Figure 5-5-2: Main view</p>	<p>Figure 5-5-3: Specific Changes</p>	<p>Figure 5-5-4: View the type display</p>

Details display:



Label;

Activity Indicator:

- a. : Device in maintenance mode;
- b. : Out of order;
- c. : Alarm Inhibition;



- d.  : Device in Operator mode;
- e.  : Communication failure;
- f.  : Invalid conFIGuretion;
- g.  : An interview muting is active;
- h.  : Enter or PV (operating variable) uncertain;

View B;

Value;

Intervention thresholds:

- i.  : HH the intervention threshold;
- j.  : Action Level H;
- k.  : The action level;
- l.  : LL action level;

Alarm Presence:

- m. Blanc: The alarm cause is no longer present, necessary acquittal;
- n. Light Blue: Information Alarm;
- o. Yellow: Warning;
- p. Red: Exception;
- q. Magenta: Fault;


Indication unit of measurement.



5.3.2 OBJECT FOR B "DIGITAL SIGNALS"

<p align="center">Figure 5-5-5: Main view</p>	<p align="center">Figure 5-5-6: View the type display</p>

Details display:



- A. Label;
- B. Status indicator:
 - a. : Alternate PV in use;
 - b. : Alarm Inhibition (removed or disabled);
 - c. : Invalid conFIGuration
- C. Mnemonic indicator associated with the value of the digital input;
- D. : Fault Indicator / O
- E. Alarm Presence:
 - a. White: The alarm cause is no longer present, necessary acknowledge;
 - b. Light Blue: Information Alarm;



- c. Yellow: Warning;
- d. Red: Exception;
- e. Magenta: Fault;

5.3.3 C OBJECT FOR "ELECTRICAL EQUIPMENT"

<p align="center">Figure 5-5-7: Main view</p>	<p align="center">Figure 5-5-8: View the type display</p>

Details display:



A. State Equipment:

- a. Blue: By train to stop;
- b. Grey: Stopped;
- c. Blue: starting up;
- d. Dark Green: Running


B. Status indicator:

- a. : Device in maintenance mode;
- b. : Device in Manual mode (local);



- c.  : The device has been disabled;
- d.  : Device in Operator mode;
- e.  : Override Device in manual (override).

Command window Details:



- Block Operator Position (Manual);
- Unblock Operator position;
- Owner of the order:
 - a. Operator;
 - b. Program (automatic);
 - c. Override;
- Manual stop control;
- Manual start command;
- Current state of equipment



5.3.4 OBJECT FOR "RUN COUNTER HOURS"




Figure 5-5-9. Main View


5.3.5 OBJECT FOR E "VALVES ALL OR NOTHING"



Figure 5-5-10: Main view



Details display:



A. : State solenoid coils:

- a. Gray: No line reel;
- b. Turquoise powered reel;

B. State of the valve:

- a. Blue: In the process of closing;
- b. Grey: Closed;
- c. Blue: In the process of opening;
- d. Dark green: Open;

C. Status Indicators:

- a.  : Device in maintenance mode;
- b.  : Device in Manual mode (local);
- c.  : The device has been disabled;
- d.  : Device in Operator mode;
- e.  : Override Device in manual (override);
- f.  : Alarm Inhibition (removed or disabled);
- g.  : Communication Failure (outdated);
- h.  : Invalid conFiguretion;

D. See C;


E. Label of the valve;



F. Alarm indicator:

- a. Blanc: The alarm cause is no longer present, necessary acquittal;
- b. Light Blue: Information Alarm;
- c. Yellow: Warning;
- d. Red: Exception;
- e. Magenta: Fault;

Command window Details:



- A. Block Operator Position (Manual);
- B. Unblock Operator position;
- C. Owner of the order:
 - a. Operator;
 - b. Program (automatic);
 - c. Override;
- D. Manual closing command;
- E. Manual opening command;
- F. Current state of the valve



5.3.6 OBJECT FOR F "REGULATOR PID"



Figure 5-5-11: View the type display




Figure 5-5-12: Main view




Figure 5-5-13: View changes





Figure 5-5-14: Window view settings




Main control Details:



- A. PID label;
- B. Value of the reference (SP = setpoint);
- C. Value of the operating variable (PV);
- D. Auto Selector;
- E. Manual mode selector;
- F. Value of the controller output (Control Variable = CV);
- G. Desired setpoint value;
- H. The set rate of change;
- I. Instant Mode setpoint change (H point rate has no effect);
- L. Push button and indicator for the presence of an anomaly;
- M. Push button to access the window changes




Details window changes:



- A. Push button to access the adjustment window controls;
- B. Legend PV (operating variables);
- C. Legend SP (instructions);
- D. Legend CV (control variables)



Details window setting control parameters:



- A. Desired value of the proportional gain;
- B. The proportional gain variation rate;
- C. Fashion instantaneous change of the proportional gain (rate B has no effect);
- D. Integration time;

5.4 ALARM MANAGEMENT

Alarm management is accomplished through a list always in the foreground located at the foot of the screen page (ref. Figure 5-5-15), With a set of indicators and controls always right foreground on the page (ref. Figure 5-5-16) And with a specialized window (ref. Figure 5-5-17).



Figure 5-5-15: Alarm list at bottom of page



Figure 5-5-16 Signaling and controls for alarm management



!	🔔	Event Time	TAG	Message	Type
🔔	🔔	10/11/2011 10:53:14 AM	PT_9G_IS_FIRST_ALM	PLUS BAS PRESSION GAZ ALIMENTATION EST LA PREMIERE	TRIP
🔔	🔔	10/11/2011 10:53:14 AM	PT_9G_STS_LL_ALM	PLUS BASSE PRESSION ENTREE AIRE GAZ DE ALIMENTATION	ALARM
🔔	🔔	10/11/2011 10:53:14 AM	PT_9G_STS_L_ALM	ALARME BASSE PRESSION ENTREE AIRE GAZ DE ALIMENTATION	ALARM
🔔	🔔	10/10/2011 9:33:58 AM	GT_ALR_EXH_T3_ALM	ETAT DE DEFAUT DU DETECTEUR DE TEMPERATURE T3 DECHARGE TURBINE	ALARM
🔔	🔔	10/10/2011 9:33:58 AM	GT_ALR_SPD_PU2_ALM	ALARM DEFAUT PICK-UP VITESSE 2	ALARM
🔔	🔔	10/10/2011 9:33:58 AM	GT_ALR_SPD_PU1_ALM	ALARM DEFAUT PICK-UP VITESSE 1	ALARM
🔔	🔔	10/10/2011 9:33:58 AM	GT_ALR_EXH_T4_ALM	ETAT DE DEFAUT DU DETECTEUR DE TEMPERATURE T4 DECHARGE TURBINE	ALARM
🔔	🔔	10/10/2011 9:33:58 AM	GT_ALR_CHIMNEY_T4_ALM	ALARME DEFAUT DETECTEUR TEMPERATURE CHEMINEE DE LA TURBINE T4	ALARM
🔔	🔔	10/10/2011 9:33:58 AM	INV_RD_ALM	REGULATEUR DE VITESSE M.L.PRET A MARCHER (CUMULATIF ALARME)	ALARM
🔔	🔔	10/10/2011 9:33:58 AM	INV_RNFR_ALM	CONTROL F DE MARCHÉ MOTEUR DE LANCÉMENT IMMÉDIAT (ALARME)	ALARM

No message selected.

170 🔔 3 ✓ 167 🚫 0

Figure 5-5-17: Window dedicated to alarms

5.4.1 CHARACTERIZING PHASE ALARMS

When an alarm occurs, it is present as a first array element of Figure 5-5-15. This condition is represented with the symbol  indicating not yet acknowledged by the operator alarms.

When this event occurs, the siren starts to ring (if it is not already ringing) and symbol  appears in the region of Figure 5-5-16.

The event that caused the alarm is stored on a specialized element, which must be reset to remove the alarm from the list, once the cause is no longer present. The reset action of alarm and siren deactivation is accomplished by means of the RESET push-button located in the Figure 5-5-16.

The area shown in the Figure 5-5-16 has two leds that are lit in case of:

- Presence of at least one alarm: CUMULATIVE ALARM;
- Presence of at least one trigger: TRIGGER CUMULATIVE;

To access the full list of existing alarms must press  which provides access to the window Figure 5-5-17.




Figure 5-5-18: Details of the window dedicated to alarms

Compared to the Figure 5-5-18 :

A. All commands:

- : Acknowledgement of selected alarms;
- : Acknowledgement of alarms selected with the addition of a comment;
- : Acknowledge all alarms displayed on the page;
- : Acknowledge all alarms contained in the list;
- : Shows details for the selected alarms;
- : Prints the alarm list;
- : Defines alarm visualization of the order;
- : Run a search in the alarm list;

B. Bar containing the titles of the displayed fields: If you select the title you force the order of the list based on the corresponding tag;

C. Alarm status:

- : Unacknowledged alarm;
- : Alarm paid;

D. Auxiliary information:

- : Led indicating the correct operation of the alarm monitoring system;
- : Number of events present in the list;
- : Number of unacknowledged alarms;
- : Number of non-rearmed but acknowledged alarms;



5.4.2 ACTIONS TO BE PERFORMED IN CASE OF OCCURRENCE OF AN ALARM

The actions to be taken in case of occurrence of an alarm are:


- Turn off the siren;
- Understand what it is alarm;
- Check the option to remove the cause that caused it, see 8.1 ;
- Acknowledge the alarm;
- Repeat the above actions for all alarms.



5.5 OVERVIEW SCREEN PAGES


5.5.1 MAIN MENU

This page is a summary of all the screen pages. Through pushbuttons is possible to access the corresponding screen page.



5.5.2 P&ID: GAS DISCHARGE


View 6.2






5.5.3 P & ID: SYSTEM LUBRICATING OIL AND MOUTH

View 6.3



5.5.4 P & ID: AIR INSTRUMENTS


View 6.4






5.5.5 P & ID: CONTROL PAGE

View 6.5 and 6.6




5.5.6 P & ID: 1st STAGE COMPRESSOR






5.5.7 P & ID: 2nd STAGE COMPRESSOR






5.5.8 P & ID: A GEAR BOX



5.5.9 CONTROLLER: TURBINE


View 6.6





5.5.10 CONTROLLER: ANTISURGE CONTROL

View 6.6



5.5.11 MOS: MANUAL BYPASS LOCKS

ID	Description	MOS
TSHH_1_1_MOS	TEMPERATURE CHAMBRE DE COMBUSTION TURBINE	MOS
TSHH_1_2_MOS	TEMPERATURE CHAMBRE DE COMBUSTION TURBINE	MOS
TSHH_2_1_MOS	TEMPERATURE CHAMBRE DE COMBUSTION TURBINE	MOS
TSHH_2_2_MOS	TEMPERATURE CHAMBRE DE COMBUSTION TURBINE	MOS
TSHH_3_1_MOS	TEMPERATURE CHAMBRE DE COMBUSTION TURBINE	MOS
TSHH_3_2_MOS	TEMPERATURE CHAMBRE DE COMBUSTION TURBINE	MOS
TSHH_4_1_MOS	TEMPERATURE CHAMBRE DE COMBUSTION TURBINE	MOS
TSHH_4_2_MOS	TEMPERATURE CHAMBRE DE COMBUSTION TURBINE	MOS
TSHH_5_1_MOS	TEMPERATURE CHAMBRE DE COMBUSTION TURBINE	MOS
TSHH_5_2_MOS	TEMPERATURE CHAMBRE DE COMBUSTION TURBINE	MOS
TSHH_6_1_MOS	TEMPERATURE CHAMBRE DE COMBUSTION TURBINE	MOS
TSHH_6_2_MOS	TEMPERATURE CHAMBRE DE COMBUSTION TURBINE	MOS
TE_6B_STS_HH_MOS	TEMPERATURE DE SORTIE HUILE PALIER GEN COTE EXC	MOS
TE_8_STS_HH_MOS	TEMPERATURE CHÉMINÉE TURBINE	MOS
TE_9_STS_HH_MOS	TEMPERATURE CHÉMINÉE TURBINE	MOS
TE_12_STS_HH_MOS	TEMPERATURE PALIER D'EPÉE TURBINE	MOS
TE_13_STS_HH_MOS	TEMPERATURE PALIER FROID TURBINE	MOS
TE_33_STS_LL_MOS	TEMPERATURE GAZ D'ALIMENTATION	MOS
TE_33_STS_HH_MOS	TEMPERATURE GAZ D'ALIMENTATION	MOS
TE_110_STS_HH_MOS	TEMPERATURE PALIER GENERATEUR COTE EXCITATION	MOS



MOS: COMMANDE MANUEL BYPASS VERROUILLAGES

TE_111_STS_HH_MOS	TEMPERATURE PALIER GENERATEUR COTE TURBINE	MOS	●
TE_200_STS_HH_MOS	OIL HEADER TEMPERATURE	MOS	●
TE_203_STS_HH_MOS	TURBINE THRUST BEARING OUTLET OIL TEMPERATURE	MOS	●
TE_204_STS_HH_MOS	TURBINE COLD BEARING OUTLET OIL TEMPERATURE	MOS	●
PT_1_STS_LL_MOS	LUBE OIL HEADER PRESSURE	MOS	●
PT_9G_STS_LL_MOS	PRESSION ENTREE GAZ DE ALIMENTATION	MOS	●
PDT_205_1_STS_HH_MOS	FUEL GAS FILTER DIFF PRESSURE	MOS	●
LSHH_205_4_FINE_IN_MOS	FUEL GAS SEPARATOR HIGH HIGH LEVEL	MOS	●
OCC_SDTB_FINE_IN_MOS	DI FROM GCP :SHUTDOWN TURBINE	MOS	●
INV_EMRC_FINE_IN_MOS	DI FROM ESM INVERTER : EMERGENCY	MOS	●

PAID: GAZ DE REFOULEMENT PAID: SYSTEME HUILE DE GRAISSAGE ET BOUCHE
 PAID: AIR DES INSTRUMENTS PAID: PAGE DE CONTROLE
 PAID: GENERATEUR ELECTRIQUE PAID: BOITE A ENGRENAGES
 CONTROLLEUR TURBINE CONTROLLEUR GENERATEUR ELECTRIQUE
 MOS DIAGNOSTIQUE
 ENTrees DIGITALES TABLEAU SIGNAUX ENTREE TABLEAU MCC
 SEUIL ANALOGIQUES IMPRIMER DATA LOGGING
 MENU PRINCIPAL ADMINISTRATION

ALARME CUMULATIF DECLENCHEMENT COMMUN
 RESET DES ALARMES

PANNEAU INSTRUMENTATION

DÉMARRAGE ACTIVE

ARRÊT D'URGENCE

PRÊT AU DÉMARRAGE DÉMARRAGE ACTIVÉ
 VITESSE: 0.1 rpm TEMP. DU COMBUSTEUR: 0.0 °C
 COP: 0.00 K/gpm TEMP. D'ÉCHAPPEMENT: 0.0 °C
 CHARGE: 0.0 % TEMP. DU CHEMINÉE: 0.0 °C
 VANNE DÉMARRAGE: -100 % VANNE MESUR. GAZ COMB: -100 %

GOTO Pg.1 ← Pg.2/2

10/11/2011 10:53:14 AM PT_9G_STS_LL_ALARM PLUS BAS PRESSION GAZ ALIMENTATION EST LA PREMIERE ALARME BASSE PRESSION ENTREE AIRE GAZ DE ALIMENTATION ALARME TRIP ALARM

Pages (2 in total) make available a selector; called MOS (Manual Override Switch) for certain causes trigger to avoid certain conditions that otherwise would cause the outbreak of the machine. In the displayed page, the MOS refers to the trigger caused by the intervention of the high temperature threshold for the TE-1 instrument. Activation of a MOS because the occurrence of an alarm.

5.5.12 DIAGNOSTIC

The page shows colorful animations by the presence of faults in the PLC system.

DIAGNOSTIQUE

CPU_1

CNET_1A_FAIL

CNET_1A_FAIL

CNET_1B_FAIL

CNET_1A

CNET_3

CNET_4

CNET_3_FAIL TC_1_FAIL TC_2_FAIL CNET_4_FAIL MCM_1_FAIL AI_2_FAIL
 TC_3_FAIL CFM_1_FAIL AI_1_FAIL AI_3_FAIL AI_4_FAIL AO_2_FAIL
 AO_1_FAIL DI_1_FAIL DI_2_FAIL DI_3_FAIL DI_4_FAIL DI_5_FAIL
 DO_1_FAIL TC_4_FAIL DO_2_FAIL DO_3_FAIL DO_4_FAIL
 DNB_FAIL

CNET_1B

TABLEAU MCC TURBINE

GAS_TURBINE_MCC_FAIL DKG_1_0_1_FAIL
 DKG_1_0_2_FAIL DKG_1_0_3_FAIL

PAID: GAZ DE REFOULEMENT PAID: SYSTEME HUILE DE GRAISSAGE ET BOUCHE
 PAID: AIR DES INSTRUMENTS PAID: PAGE DE CONTROLE
 PAID: GENERATEUR ELECTRIQUE PAID: BOITE A ENGRENAGES
 CONTROLLEUR TURBINE CONTROLLEUR GENERATEUR ELECTRIQUE
 MOS DIAGNOSTIQUE
 ENTrees DIGITALES TABLEAU SIGNAUX ENTREE TABLEAU MCC
 SEUIL ANALOGIQUES IMPRIMER DATA LOGGING
 MENU PRINCIPAL ADMINISTRATION

ALARME CUMULATIF DECLENCHEMENT COMMUN
 RESET DES ALARMES

PANNEAU INSTRUMENTATION

DÉMARRAGE ACTIVE

ARRÊT D'URGENCE

PRÊT AU DÉMARRAGE DÉMARRAGE ACTIVÉ
 VITESSE: 0.1 rpm TEMP. DU COMBUSTEUR: 0.0 °C
 COP: -0.00 K/gpm TEMP. D'ÉCHAPPEMENT: 0.0 °C
 CHARGE: 0.0 % TEMP. DU CHEMINÉE: 0.0 °C
 VANNE DÉMARRAGE: -100 % VANNE MESUR. GAZ COMB: -100 %

10/11/2011 10:53:14 AM PT_9G_STS_LL_ALARM PLUS BAS PRESSION GAZ ALIMENTATION EST LA PREMIERE ALARME BASSE PRESSION ENTREE AIRE GAZ DE ALIMENTATION ALARME TRIP ALARM



5.5.13 DIGITAL INPUTS TABLE

The pages list the digital inputs managed by the internal board cards UCP.

ENTRÉES DIGITALES TABLEAU CNET_3

CNET_3:7 1756-IB16I DI_1

T0-2 OFF	ZSH-1 ALARM	ZSH-4 ON	PSH-6 ON
LSL-10 ALARM	ZSL-1 ON	ZSL-4 ON	ZSH-100 CHARGER
LEH200R TRIP	ZSH-2 ON	ZSH-6 ON	ZSH-101 ON
ZSH-VBY ON	ZSL-2 ON	ZSL-6 ON	

CNET_3:8 1756-IB16I DI_2

PSL-06 LOW	HSSE-M-1-STR AUTO	HS-GQZ1 OFF	E-2-INV-RNFB ON
PSL-36 ALARM	HSSE-M-1-STOP STOP	E1-INV-RNFB ON	E2-INV-OVLD ON
PDSH-32 ALARM	PSSL202Z/S ALARM	E1-INV-OVLD ON	FGV-3-F ON

PANNEAU INSTRUMENTATION

DÉMARRAGE ACTIVE

ARRÊT D'URGENCE

PRÊT AU DÉMARRAGE (OFF) / DÉMARRAGE ACTIVÉ (ON)

YITESSE: 0.1 rpm / TEMP. DU COMBUSTEUR: 0.0 °C

COP: -0.00 KJ/gm / TEMP. D'ÉCHAUFFEMENT: 0.0 °C

CHARGE: 0.0 % / TEMP. DU CHÂSSIS: 0.0 °C

VANNE DÉMARRAGE: -10.0 % / VANNE MESUR. GAZ COMB: -10.0 %

ALARME CUMULATIF (OFF) / DÉCLENCHEMENT COMMUN (OFF)

RESET DES ALARMES

LOG: 10/11/2011 10:53:14 AM PT_96_STS_L_1_ALM PLUS BAS PRESSION GAZ ALIMENTATION EST LA PREMIERE ALARME BASSE PRESSION ENTRÉE AIRE GAZ DE ALIMENTATION

ENTRÉES DIGITALES TABLEAU CNET_4

CNET_4:6 1756-IB16I DI_3

QCO-RC ON	QCO-SDBT TRIP	ECC-EFB OFF	INV-RNFB ON
QCO-AS MURFAL	QCO-EPRM ON	INV-TBOIF ALARM	INV-ALM ALARM
QCO-RS ON	QCO-S29ST OPEN	INV-ED READY	
QCO-LB ON	QCO-GMK ON	INV-CMD LOCAL	

CNET_4:7 1756-IB16I DI_4

LSH200S ALARM	FG-OP-2 ALARM
FG-PR-AL ALARM	FG-OP-6 ALARM
FG-ALMS ALARMS	FG-ALM-GEN ALARM

CNET_4:8 1756-IB16I DI_5

INV-EMRG ALARM	INT-FB-SP TRIP	INT-4H-VB TRIP	INT-4-TEMP ALARM
E1-INV-FAULT ALARM	INT-P-E-F ALARM	INT-PWA-F ALARM	INT-ED-F ALARM
E2-INV-FAULT ALARM	INT-HB-F ALARM	INT-PWB-F ALARM	

PANNEAU INSTRUMENTATION

DÉMARRAGE ACTIVE

ARRÊT D'URGENCE

PRÊT AU DÉMARRAGE (OFF) / DÉMARRAGE ACTIVÉ (ON)

YITESSE: 0.1 rpm / TEMP. DU COMBUSTEUR: 0.0 °C

COP: -0.00 KJ/gm / TEMP. D'ÉCHAUFFEMENT: 0.0 °C

CHARGE: 0.0 % / TEMP. DU CHÂSSIS: 0.0 °C

VANNE DÉMARRAGE: -10.0 % / VANNE MESUR. GAZ COMB: -10.0 %

ALARME CUMULATIF (OFF) / DÉCLENCHEMENT COMMUN (OFF)

RESET DES ALARMES

LOG: 10/11/2011 10:53:14 AM PT_96_STS_L_1_ALM PLUS BAS PRESSION GAZ ALIMENTATION EST LA PREMIERE ALARME BASSE PRESSION ENTRÉE AIRE GAZ DE ALIMENTATION

5.5.14 INPUT SIGNALS TABLE MCC

The pages list the digital inputs managed by internal boards MCC chart.



SIGNAUX ENTRÉE TABLEAU MCC

ENTRÉES DIGITALES

GAS TURBINE MCC:0:1 1794-IB16XOB16P/A DIG | O | 1

MS-IN001	MS-IN005	MS-IN111
ON	-	-
MS-IN011	MS-IN081	MS-IN131
ON	ON	RUN
MS-IN021	MS-IN091	MS-IN151
ON	RUN	ON
MS-IN051	MS-IN101	-
ON	ON	-

GAS TURBINE MCC:0:1 1794-IB16XOB16P/A DIG | O | 3

MS-IN003	MS-IN053	MS-IN103
RUN	-	-
MS-IN013	MS-IN063	MS-IN113
-	RUN	-
MS-IN023	MS-IN083	MS-IN133
-	-	-
MS-IN043	MS-IN093	MS-IN143
ON	-	-

GAS TURBINE MCC:0:1 1794-IB16XOB16P/A DIG | O | 2

MS-IN002	-
ON	-
MS-IN112	-
POWER ON	-
MS-IN122	-
-	-

ALARME CUMULATIF DÉCLENCHEMENT COMMUN

RESET DES ALARMES

PANNEAU INSTRUMENTATION

DÉMARRAGE ACTIVÉ ARRÊT D'URGENCE

PRÊT AU DÉMARRAGE DÉMARRAGE ACTIVÉ

VITESSE: 5.1 rpm TEMP. DU COMBUSTEUR: 0.0 °C

COP: -0.00 K g/km TEMP. D'ÉCHAPPEMENT: 0.0 °C

CHARGE: 0.0 % TEMP. DU CHÊMINÉE: 0.0 °C

VANNE DÉMARRAGE: -10.0 % VANNE MESUR. GAZ COMB: -10.0 %

10/11/2011 10:53:14 AM PT_9G_STS_L_ALM PLUS BAS PRESSION GAZ ALIMENTATION EST LA PREMIERE ALARME BASSE PRESSION ENTRÉE AIRE GAZ DE ALIMENTATION

5.5.15 SIMILAR THRESHOLD

Pages (3 total) reported the thresholds associated with the analog instrumentation with an explanation of their effect.

SEUIL ANALOGUES

TAG	EU	LL	L	H	HH	ACTION
FOV-3-FDB	%					--
PDT-11	mBar			1000,0		--
PDT-205	mBar					--
PT-A	Barg		2,00			--
PT-05	Barg	0,90	0,92			--
PT-1	Barg	0,59	0,85			LL ALARME: FERMÉE CHAUFFE BHI; NON L ALARME: PERMISSIF AU DÉMARRAGE; DÉMARRÉE POMP HUILE D'URGENCE FERMÉE POMP HUILE D'URGENCE
PT-1 EU_VAL	Barg		0,58			NON L ALARME: PERMISSIF AU VIRATEUR
PT-3	Barg		5,00	6,37		L: DÉMARRÉE POMP HUILE AUXILIAIRE H: ARRÊT POMP HUILE AUXILIAIRE
PT-6	Barg					--
PT-7	Barg	1,5E38	0,85			LL ALARME: ACTIVÉE APRÈS ALLUMAGE NON L ÉTAT: PERMISSIF AU DÉMARRAGE
PT-8	Barg		0,50			ACTIVÉE APRÈS DÉMARRAGE
PT-9G	Barg	3,00	9,50			NON L ALARME: PERMISSIF AU DÉMARRAGE
PT-11	Barg		2,80			--
PT-16G	Barg					--
TE-1	°C				700,0	SEUIL POR LE DEMARRAGE
TE-2	°C				700,0	SEUIL POR LE DEMARRAGE
TE-3	°C				700,0	SEUIL POR LE DEMARRAGE
TE-4	°C				700,0	SEUIL POR LE DEMARRAGE
TE-5	°C				700,0	SEUIL POR LE DEMARRAGE
TE-6	°C				700,0	SEUIL POR LE DEMARRAGE
TE-1..6	°C			600,0	700,0	TEMPERATURE MOIENNE CHAMBRE DE COMBUSTOR, SEUIL POR LE DEMARRAGE

ALARME CUMULATIF DÉCLENCHEMENT COMMUN

RESET DES ALARMES

PANNEAU INSTRUMENTATION

DÉMARRAGE ACTIVÉ ARRÊT D'URGENCE

PRÊT AU DÉMARRAGE DÉMARRAGE ACTIVÉ

VITESSE: 5.1 rpm TEMP. DU COMBUSTEUR: 0.0 °C

COP: -0.00 K g/km TEMP. D'ÉCHAPPEMENT: 0.0 °C

CHARGE: 0.0 % TEMP. DU CHÊMINÉE: 0.0 °C

VANNE DÉMARRAGE: -10.0 % VANNE MESUR. GAZ COMB: -10.0 %

10/11/2011 10:53:14 AM PT_9G_STS_L_ALM PLUS BAS PRESSION GAZ ALIMENTATION EST LA PREMIERE ALARME BASSE PRESSION ENTRÉE AIRE GAZ DE ALIMENTATION



SEUIL ANALOGUES

TAG	EU	LL	L	H	HH	ACTION
ECC-CRR	A					--
ECC-VLT	V					--
TE-1 TSHH	°C				950,0	SEUIL POR LE MARCHE NORMAL
TE-2 TSHH	°C				950,0	SEUIL POR LE MARCHE NORMAL
TE-3 TSHH	°C				950,0	SEUIL POR LE MARCHE NORMAL
TE-4 TSHH	°C				950,0	SEUIL POR LE MARCHE NORMAL
TE-5 TSHH	°C				950,0	SEUIL POR LE MARCHE NORMAL
TE-6 TSHH	°C				950,0	SEUIL POR LE MARCHE NORMAL
TE-1.6 TSHH	°C			855,0	950,0	TEMPERATURE MOIENNE CHAMBRE DE COMBUSTOR SEUIL POR LE MARCHE NORMAL
TE-T1	°C					--
TE-T2	°C					--
TE-T3	°C					--
TE-T4	°C					--
TE-T1.4	°C			450,0	480,0	TEMPERATURE MOIENNE ECHAPPEMENT TURBINE
TE-7	°C			430,0		
TE-8	°C				450,0	
TE-9	°C				450,0	
TE-10	°C					
TE-10A	°C					
TE-10B	°C					
TE-7..10B	°C			600,0	700,0	TEMPERATURE MOIENNE CHAMBRE DE COMBUSTOR DEMARRAGE

GOTO PG.1 ← PG.23 → GOTO PG.2

▲ 10/11/2011 10:52:14 AM PT_96_STS_L_ALM PLUS BAS PRESSION ENTREE AIR GAZ DE ALIMENTATION ALARME TRIP ALARM
▲ 10/11/2011 10:53:14 AM PT_96_IS_FIRST_ALM PLUS BAS PRESSION GAZ ALIMENTATION EST LA PREMIERE
▲ 10/11/2011 10:53:14 AM PT_96_STS_L_ALM ALARME BASSE PRESSION ENTREE AIRE GAZ DE ALIMENTATION

▲ 3 ✓ 166 ▲ 4 ● 0

PAID: GAZ DE REFROIDEMENT PAID: SYSTEME HUILE DE GRAISSAGE ET BOUCHE

PAID: AIR DES INSTRUMENTS PAID: PAGE DE CONTRÔLE

PAID: GÉNÉRATEUR ÉLECTRIQUE PAID: BOÎTE À ENGRENAGES

CONTRÔLEUR TURBINE

MOS

ENTRÉES DIGITALES TABLEAU

SEUIL ANALOGUES

MENU PRINCIPAL

CONTRÔLEUR GÉNÉRATEUR ÉLECTRIQUE

DIAGNOSTIQUE

SIGNAUX ENTRÉE TABLEAU MCC

IMPRIMER DATA LOGGING

ADMINISTRATION

ALARME CUMULATIFDÉCLENCHEMENT COMMUN

RESET DES ALARMES

DÉMARRAGE ACTIVÉ

ARRÊT D'URGENCE

● PRÊT AU DÉMARRAGE

● DÉMARRAGE ACTIVÉ

VITESSE 5,7 rpm

TEMP. DU COMBUSTEUR 0,0 °C

CDP -0,0X Kghm

TEMP. D'ÉCHAPPEMENT 0,0 °C

CHARGE 0,0 %

TEMP. DU CHÉMINÉE 0,0 °C

VANNE DÉMARRAGE -10,0 %

VANNE MESUR. GAZ COMB -10,0 %

SEUIL ANALOGUES

TAG	EU	LL	L	H	HH	ACTION
TE-1A	°C			75,0	100,0	--
TE-6A	°C			70,0		--
TE-6B	°C				1,5E38	--
TE-11	°C					--
TE-12	°C			95,0	115,0	--
TE-13	°C			95,0	115,0	--
TE-14	°C					--
TE-17	°C					--
TE-17A	°C			80,0		--
TE-33	°C	10,0	15,0		60,0	--
TE-110	°C			95,0	105,0	--
TE-111	°C			95,0	105,0	--
TE-113	°C			75,0		--
TE-114	°C			75,0		--
TE-116	°C			55,0		--
TE-116	°C			55,0		--
TE-200	°C			60,0	70,0	--
TE-201	°C		30,0	55,0		--
TE-202	°C					--
TE-203	°C			70,0	100,0	--
TE-204	°C			70,0	100,0	--
TE-205	°C		1,5E38			--

GOTO PG.2 ← PG.33 → GOTO PG.1

▲ 10/11/2011 10:52:14 AM PT_96_STS_L_ALM PLUS BAS PRESSION ENTREE AIR GAZ DE ALIMENTATION ALARME TRIP ALARM
▲ 10/11/2011 10:53:14 AM PT_96_IS_FIRST_ALM PLUS BAS PRESSION GAZ ALIMENTATION EST LA PREMIERE
▲ 10/11/2011 10:53:14 AM PT_96_STS_L_ALM ALARME BASSE PRESSION ENTREE AIRE GAZ DE ALIMENTATION

▲ 3 ✓ 166 ▲ 4 ● 0

PAID: GAZ DE REFROIDEMENT PAID: SYSTEME HUILE DE GRAISSAGE ET BOUCHE

PAID: AIR DES INSTRUMENTS PAID: PAGE DE CONTRÔLE

PAID: GÉNÉRATEUR ÉLECTRIQUE PAID: BOÎTE À ENGRENAGES

CONTRÔLEUR TURBINE

MOS

ENTRÉES DIGITALES TABLEAU

SEUIL ANALOGUES

MENU PRINCIPAL

CONTRÔLEUR GÉNÉRATEUR ÉLECTRIQUE

DIAGNOSTIQUE

SIGNAUX ENTRÉE TABLEAU MCC

IMPRIMER DATA LOGGING

ADMINISTRATION

ALARME CUMULATIFDÉCLENCHEMENT COMMUN

RESET DES ALARMES

DÉMARRAGE ACTIVÉ

ARRÊT D'URGENCE

● PRÊT AU DÉMARRAGE

● DÉMARRAGE ACTIVÉ

VITESSE 5,7 rpm

TEMP. DU COMBUSTEUR 0,0 °C

CDP -0,0X Kghm

TEMP. D'ÉCHAPPEMENT 0,0 °C

CHARGE 0,0 %

TEMP. DU CHÉMINÉE 0,0 °C

VANNE DÉMARRAGE -10,0 %

VANNE MESUR. GAZ COMB -10,0 %



5.5.16 PRINT DATA LOGGING

If you press this push-button printing is started from the state in that time some "critical" variables for regulating the turbine.

The following reports a copy of possible impressions.

 		TG7 S/N 406 GR.1 POWER PLANT DATA LOGGING		DATE 11/10/2011 HEURE 17:21:51	
VITESSE GÉNERATEUR				5,5	RPM
POISSANCE ACTIVE				0,000	MW
PRESSION BAROMÉTRIQUE	PT-06			1,007	Bars
TEMPÉRATURE AMBIANT	TE-202 / 14	29,32 /	30,13		°C
TEMPÉRATURE GAZ	TE-33			33,3	°C
TEMPÉRATURE 1 CHAMBRE DE COMBUSTION	TE-1			32,1	°C
TEMPÉRATURE 2 CHAMBRE DE COMBUSTION	TE-2			30,9	°C
TEMPÉRATURE 3 CHAMBRE DE COMBUSTION	TE-3			30,9	°C
TEMPÉRATURE 4 CHAMBRE DE COMBUSTION	TE-4			30,0	°C
TEMPÉRATURE 5 CHAMBRE DE COMBUSTION	TE-5			30,6	°C
TEMPÉRATURE 6 CHAMBRE DE COMBUSTION	TE-6			31,4	°C
TEMPÉRATURE MOYENNE CHAMBRES DE COMBUSTION				0,0	°C
TEMPÉRATURE SORTIE COMPRESSEUR AXIAL	TE-11			28,2	°C
TEMPÉRATURE 1 ÉCHAPPEMENT TURBINE	TE-T1			32,5	°C
TEMPÉRATURE 2 ÉCHAPPEMENT TURBINE	TE-T2			30,9	°C
TEMPÉRATURE 3 ÉCHAPPEMENT TURBINE	TE-T3			33,9	°C
TEMPÉRATURE 4 ÉCHAPPEMENT TURBINE	TE-T4			31,0	°C
TEMPÉRATURE MOYENNE ÉCHAPPEMENT TURBINE				0,0	°C
TEMPÉRATURE 1 CONDUIT D'ÉCHAPPEMENT (CHEMINÉE)	TE-7			29,4	°C
TEMPÉRATURE 2 CONDUIT D'ÉCHAPPEMENT (CHEMINÉE)	TE-8			30,2	°C
TEMPÉRATURE 3 CONDUIT D'ÉCHAPPEMENT (CHEMINÉE)	TE-9			29,4	°C
TEMPÉRATURE 4 CONDUIT D'ÉCHAPPEMENT (CHEMINÉE)	TE-10			28,1	°C
TEMPÉRATURE 5 CONDUIT D'ÉCHAPPEMENT (CHEMINÉE)	TE-10A			30,3	°C
TEMPÉRATURE 6 CONDUIT D'ÉCHAPPEMENT (CHEMINÉE)	TE-10B			30,6	°C
TEMPÉRATURE MOYENNE CONDUIT D'ÉCHAPPEMENT (CHEMINÉE)				0,0	°C
TEMPÉRATURE RESERVOIR HUILLE (FOND/HAUT)	TE-201 / 205	42,15 /	42,15		°C
TEMPÉRATURE HUILLE ENTRÉE REFRIGÉRANTE	TE-17			42,15	°C
TEMPÉRATURE HUILLE SORTIE REFRIGÉRANTE (3)	TE-17A			42,67	°C
TEMPÉRATURE HUILLE COLLECTEUR ALIMENTATION PALIER	TE-200			42,22	°C
TEMPÉRATURE HUILLE DÉCHARGER PALIER TURBINE (5)	TE-1A			42,80	°C
TEMPÉRATURE HUILLE DÉCHARGER PALIER COMPRESSEUR	TE-204			33,22	°C
TEMPÉRATURE HUILLE DÉCHARGER PALIER DE BUTÉE (4)	TE 203			43,12	°C
TEMPÉRATURE METAL BLANC PALIER DE BUTÉE (ACTIF/PASSIF)	TE 13 / 12	41,34 /	42,79		°C
TEMPÉRATURE HUILLE SORTIE RÉDUCTEUR (6)	TE 6A / 6B	42,13 /	43,20		°C
TEMPÉRATURE MÉTAL BLANC PALIER ALTERNATEUR CÔTÉ RÉDUCT. (7)	TE 110			40,98	°C
TEMPÉRATURE MÉTAL BLANC PALIER ALTERNATEUR CÔTÉ EXCIT. (8)	TE 111			40,25	°C
TEMPÉRATURE AIR ENTRÉE ALTERNATEUR (CONDUIT/INTERNE)	TE 116 / 115	29,6 /	29,5		°C
TEMPÉRATURE AIR ÉCHAPPEMENT ALTERNATEUR (INTERNE/CONDUIT)	TE 114 / 113	27,5 /	27,5		°C

PAGE 1/2




				TG7 S/N 406 GR.1 POWER PLANT DATA LOGGING		DATE 11/10/2011 HEURE 17:21:52
PRESSION HUILE DÉCHARGER POMPE URGENCE/AUXILIAIRE	PT 1			1,00	Bar	
PRESSION HUILE DÉCHARGER POMPE PRINCIPAL	PT 3			1,66	Bar	
PRESSION HUILE DE SURVITESSE	PT 7			0,48	Bar	
PRESSION GRAISSAGE	PT 1			1,00	Bar	
DELTA P FILTRES HUILE	PDT 11			256,2	mBar	
PRESSION GAZ AVANT SURVITESSE SOUPAGE	PT 9G			2,000	Bar	
PRESSION DE BRULEUR	PT 16G			-0,004	Bar	
PRESSION AIR PISTON DE BALANCEMENT	PT 8			0,005	Bar	
PRESSION DE REFOULEMENT COMPRESSEUR	PT 6			-0,000	Bar	
ALTERNATEUR FRÉQUENCE				0,00	Hz	
ALTERNATEUR MOYENNE COURANT				0,00	A	
ALTERNATEUR MOYENNE TENSION				0,0	V	
ALTERNATEUR PUISSANCE ACTIVE				0,000	MW	
ALTERNATEUR PUISSANCE RÉELLE				0,000	MVar	
ALTERNATEUR PUISSANCE ACTIVE TOTAL APPROVISIONNÉ				324,492	MWh	
ALTERNATEUR PUISSANCE RÉELLE TOTAL APPROVISIONNÉ				48,043	MVarh	
ALTERNATEUR FACTEUR DE PUISSANCE				1,000		
ALTERNATEUR TEMPÉRATURE STATOR PLUS CHAUDS				28,00	°C	
VIBRATIONS MESURÉES CÔTÉ TURBINE	VT 1			0,0	ips	
VIBRATIONS MESURÉES CÔTÉ GÉNÉRATEUR (RÉDUCTEUR)	XT 103 / 104	0,078	/	0,075	mls	
VIBRATIONS MESURÉES CÔTÉ GÉNÉRATEUR (ECCITATEUR)	XT 101 / 102	0,048	/	0,054	mls	



5.5.17 ADMINISTRATION

The figure below shows the administration page of the HMI system.



The carrier selection function allows the user to select the system with the corresponding authorizations.

Access is protected by a password.

The table below shows the rights of different users:

User	Password	Operator Mode / Program	Threshold	Description, etc.	Maintenance
operator	****	X	-	-	-
engineer	****	X	X	X	-
supervisor	****	X	X	X	X

An order in this page also allows the passage of the English language to the French language.



6 FUNCTIONAL DESCRIPTION

6.1 INTRODUCTION

The purpose of this chapter is to describe the operating logic of the control system.

6.2 GAS CIRCUIT

The gas system is shown schematically in the document MD-222-09 page 3.

6.2.1 COMPONENTS

The components parts of the gas circuit, which also applies to the control system, is reported below:

- Gas Heater:
 - PSL 202/3: Alarm;
- Gas filtration skid:
 - LSHH 205/4: Triggered by the separator too high;
 - LSHH 205/3: high level alarm of the separator;
 - PDT 205/1, differential pressure at the ends of the filter:
 - Alarm per intervention threshold H;
 - Actuation by interference threshold HH;
- Transmitters:
 - TE 33, the fuel gas temperature:
 - Actuation by interference threshold HH, set @ 60 ° C;
 - Actuation by interference threshold LL, set @ 10 ° C;
 - Startup permission to temperatures above 15 ° C
 - PT 9G, fuel gas pressure at the entrance:
 - The action level alarm, set @ 9.5 bar;
 - Actuation by interference threshold LL, set @ 3 bar;
 - PT 16G, gas pressure at the exit of skid;
- Vannes ALL OUT THERE:
 - FGV 1 Stop valve of fuel gas:
 - Operated by FGV SOV 1
 - ZSH 1: Sw. open end of race
 - ZSL 1: Sw. closed limit
 - FGV 6, purge valve fuel gas:
 - Driven by SOV V2G
 - ZSH 6: interr. open end of race
 - ZSL 6: interr. closed limit
 - FGV 4, isolation valve fuel gas:
 - Powered by SOV V1G
 - ZSH 6: interr. open end of race
 - ZSL 6: interr. closed limit
- Control valves:



- FGV 2 starter valve fuel gas:
 - Actuated by a 4-20 mA signal from the table, acting through an electro converter and positioner
 - ZSH 2: interr. open end of race
 - ZSL 2: interr. closed limit
- FGV 3 Main valve fuel gas:
 - Electrically actuated by the control signal types 4-20mA from Table
 - ZSH 3: interr. open end of race
 - ZSL 3: interr. closed limit

6.2.2 OPERATION

The gas from the battery input is processed by the heating system, the operation of which is indicated by the PSSL 202/3 state that should not be in alarm. The gas is processed by the system which has the functions of separation and filtration. During normal operation, the following alarms should NOT be present:

- LAH 205/3
- LAHH 205/4
- PDAH 205/1
- PDAHH 205/1

After passing the separation-filtration system, the gas arrives at the input of the skid of the turbine gas valves. Abnormal pressure values and gas temperature cause the following events:

- TE 33, the fuel gas temperature:
 - Actuation by interference threshold HH, set @ 60 ° C;
 - Actuation by interference threshold LL, set @ 10 ° C;
 - Startup permission to temperatures above 15 ° C
- PT 9G, fuel gas pressure at the entrance:
 - The action level alarm, set @ 9.5 bar;
 - Actuation by interference threshold LL, set @ 3 bar;



6.3 OIL SYSTEMS

The oil circuit is shown schematically in the document MD-222-09 page 5.

6.3.1 COMPONENTS

The components parts of the oil circuit, which also applies to the control system, is reported below:

- Oil pumps:
 - Main pump driven by the accessory gearbox
 - Auxiliary pump: PMOA;
 - Emergency pump: PMOE;
- Fans of the oil cooler:
 - T2AB
 - T2BB
- Oil Cooler: EH1
- Oil vapor extractor: PRESS
- Transmitters / thermocouples:
 - PT 1, oil pressure to the collector:
 - Low pressure alarm @ 0.85 bar
 - Threshold L @ 0.58 bar as permission for the march to tacking
 - Triggered by pressure too low @ 0.59 bar
 - PT 3 oil discharge pressure of the mechanical pump:
 - Low pressure threshold @ 5 bar to start PMOA;
 - High pressure threshold @ 6.37 bar to start PMOA;
 - PT 7, the mechanical system pressure overspeed:
 - Low pressure threshold @ 0.85 bar as start permission;
 - Triggered by pressure too low @ 0.75 bar
 - LS 10: oil tank level status;
 - TE 201: bottom oil temperature reservoir
 - TE 205: tank top oil temperature:
 - Threshold L @ 30 ° C for management EH1 (ref. 0)
 - TE 17: upstream oil temperature of the radiator;
 - TE 17 °: downstream oil temperature of the radiator;
 - PDT 11: pressure at the ends of the filter:
 - High pressure alarm @ 1000 mbar
 - TE 200: oil temperature downstream of the filter:
 - High temperature alarm @ 60 ° C
 - Triggered by too high temperature @ 70 ° C
 - TE 1A discharge oil temperature exhaust side turbine bearing:
 - High temperature alarm @ 75 ° C
 - Triggered by too high temperature 100 ° C @
 - TE 203: Discharge oil temperature thrust bearing axial turbine compressor side:
 - High temperature alarm @ 70 ° C



- Triggered by too high temperature 100 ° C @
- TE 204: Discharge oil temperature thrust bearing axial turbine compressor side:
 - High temperature alarm @ 70 ° C
 - Triggered by too high temperature 100 ° C @
- TE 12: white metal temperature thrust bearing axial turbine compressor side:
 - High temperature alarm @ 95 ° C
 - Triggered by too high temperature 115 ° C @
- TE 13 white metal temperature thrust bearing axial turbine compressor side:
 - High temperature alarm @ 95 ° C
 - Triggered by too high temperature 115 ° C @
- TE 6A discharge oil temperature bearing gearbox, turbine side:
 - High temperature alarm @ 70 ° C
- TE 6B discharge oil temperature bearing gearbox, turbine side:
 - Triggered by too high temperature 100 ° C @
- TE 110: white metal bearing temperature turbine compressor side:
 - High temperature alarm @ 95 ° C
 - Triggered by too high temperature 105 ° C @
- TE 111: white metal bearing temperature compressor side:
 - High temperature alarm @ 95 ° C
 - Triggered by too high temperature 105 ° C @

6.3.2 **PRIOR**

All equipment listed below should be left in automatic mode:

- Oil pumps:
 - Auxiliary pump: PMOA;
 - Emergency pump: PMOE;
 - Emergency pump: RPM-3C
 - Auxiliary pump: RPM-3B
 - Main pump: RPM-3A
- Fans oil cooler:
 - T2AB
 - T2BB
- Oil Cooler: EH1
- Oil vapor extractor: PRESS

6.3.3 **OPERATION**

During operation of the turbine lubrication is guaranteed by the main pump.

During the start-up and shutdown, lubrication is guaranteed by PMOA, which starts automatically if the pressure measured by PT 3 is low.

At very low manifold pressure PT 1, the standby pump starts, PMOE. The main causes of the low pressure manifold (PT 1) are:

- Failure of the PMOA

If the oil tank is unsuitable temperatures, the radiator is on EH 1, provided that the oil is going to flow, ref. 0.



The oil circulating through the cooling radiator, where T2AB fans, T2BB, powered by the corresponding inverters, eliminate excess heat to keep the temperature measured by TE 205-50 ° C, The regulator used is 17A ICT set with reference to 50 ° C.

If the mechanical system overspeed occurs, the pressure measured by PT 7 downward and thus causes the activation of the system.



6.4 CIRCUIT AIR INSTRUMENTS

The instrument air system is shown schematically in the document MD-222-09 page 9.

6.4.1 COMPONENTS

The components parts of the air circuit instruments, which also applies to the control system, is reported below:

- Air treatment system DRY-COOLER
- Solenoid:
 - SOV 10 for controlling the anti-surge valve VBY axial compressor
 - SOV V2G, for controlling the FGV6 valve
 - SOV V1G for control of FGV4 valve
- Transmitters:
 - PT A, discharge pressure of the air compressor:
 - Low pressure alarm @ 2 bar
 - PT 11, pressure to the compressed air manifold
 - Low pressure alarm @ 2.8 bar
 - PT 8, pressure compensating cylinder
 - Low pressure alarm @ 0.6 bar
 - PT 6, axial compressor discharge pressure
- Digital Instruments:
 - HSP 6, axial compressor discharge pressure switch:
 - Set @ 0.4 bar
 - ZSH VBY: limit switch anti-surge valve opening;
 - ZSL VBY: end of anti-surge valve closing stroke;



6.5 CIRCUIT COMBUSTION AIR AND BURNING

The combustion air circuit and the combustion is shown schematically in document MD-222-09 on page 7. For specific descriptions of the operation of turbine regulator, see 6.6.

6.5.1 COMPONENTS

The list of the component parts of the combustion air system and combustion, which also applies to the control system, is reported below:

- Electrical equipment:
 - S-EM1, sand extractor
 - SQZ1, cleaning system filter room:
 - 35 PSL: low air pressure to the hallway of the cleaning system (pulse-jet);
 - PDAH 32: high differential pressure at the ends of the filter chamber;
 - VIR, rotator:
 - Protecting the motor shaft turning gear mounted properly: ZSH 100;
 - ESM Starting electric motor:
 - During torque transfer clutch (engaged): ZSH 101;
 - Spark plugs ÷ TR6 TR1;
- Transmitters / thermocouples:
 - TE 202, filter room air temperature;
 - TE 14, turbine inlet air temperature;
 - PT 05 turbine inlet air pressure:
 - Low pressure alarm per intervention threshold;
 - Actuation by interference too low pressure threshold;
 - TE-11, air temperature at the outlet of the axial compressor;
 - TE-1, 1-temperature combustion chamber:
 - Triggered by too high temperature at start @ 700 ° C;
 - Triggered by too high temperature load condition @ 950 ° C;
 - TE-2, combustion chamber temperature 2:
 - Triggered by too high temperature at start @ 700 ° C;
 - Triggered by too high temperature load condition @ 950 ° C;
 - TE-3, combustion chamber temperature 3:
 - Triggered by too high temperature at start @ 700 ° C;
 - Triggered by too high temperature load condition @ 950 ° C;
 - TE-4, combustion chamber temperature 4:
 - Triggered by too high temperature at start @ 700 ° C;
 - Triggered by too high temperature load condition @ 950 ° C;
 - TE-5, 5 combustion chamber temperature:
 - Triggered by too high temperature at start @ 700 ° C;
 - Triggered by too high temperature load condition @ 950 ° C;
 - TE-6, 6-temperature combustion chamber:
 - Triggered by too high temperature at start @ 700 ° C;



- Triggered by too high temperature load condition @ 950 ° C;
- TE-T1, turbine exhaust temperature;
- TE-T2, turbine exhaust temperature;
- TE-T3, turbine exhaust temperature;
- TE-T4, turbine exhaust temperature;
- TE-7, temperature exhaust chimney pipe:
 - High temperature alarm @ 430 ° C;
- TE-8, temperature exhaust chimney pipe:
 - Triggered by too high temperature @ 450 ° C;
- TE-9-temperature exhaust chimney pipe:
 - Triggered by too high temperature @ 450 ° C;
- TE-10 temperature exhaust chimney pipe;
- TE-10A-temperature exhaust chimney pipe;
- TE-10B-temperature exhaust chimney pipe;
- VT-1. Turbine Vibration:
 - High vibration alarm threshold during startup @ 6 fps;
 - High vibration alarm threshold during start @ 8 fps;
 - High vibration alarm threshold for the charging plug @ 3 fps;
 - High vibration alarm threshold for the charging plug @ 4 fps;

6.5.2 PRIOR

All attachments listed below should be left in automatic mode:

- S-EM1, sand extractor;
- SQZ1, cleaning system filter room;
- VIR, rotator

6.5.3 OPERATION

The incoming air to the intake of the turbine axial compressor goes through the room S-EM1 filters and extracted from the chamber the sand collected on the bottom of the space upstream of the filters. When S-EM1 is running one of the following conditions happen:

- DPA-32;
- Manual Request for operator pushbutton: HSSEM_1_STR;

Automatic sequence of cleaning system (pulse-jet) is started.

When the filter status is compromised, the pressure measured by PT-5 will tend to assume still lower values, reaching the threshold value too low causes the turbine trip.

The ZSH-100 signal strength stop tacking VIR in order to prevent accidents during the manual shift operations.

The ZSH-101 signal indicates whether the clutch by which the starter motor provides torque to the turbine is engaged or not.

The management of these signals:

- PT-6;
- HSP-6;
- TE-TE-1 ÷ 6;
- TE-TE-T1 ÷ T4;
- TE-TE-7 ÷ 10B;

And management of the following electrical equipment:

- ESM;



- VIR;
- SP1 ÷ SP6;



6.6 TURBINE CONTROL

The control of the turbine is divided into two phases. The first is the startup / shutdown of the turbine and the second load management. The two phases are managed in two HMI control pages:

1. Control: Turbine
2. Control: Antisurge




Figure 6-1 Turbine control




Figure 6-2 Antisurge control



6.6.1 COMPONENTS

The instruments involved in the control of the turbine are many and below we offer a list:

- Speed Sensors (ST-SR1,2)
- Temperatures combustion chambers (TE-1..6)
- Turbine exhaust temperatures (TE_T1..T4)
- Temperatures exhaust pipe - chimney (TE-7..10B)
- Barometric pressure (PT-05)
- Axial compressor discharge pressure switch (PSH-6)
- Axial compressor discharge pressure (PT-6)
- Rotator (VIR)
- Starter motor (ESM)
- Gas line valves
 - Overspeed FGV1 by SOV-solenoid FGV1
 - FGV6 evacuation by the SOV-V2G solenoid
 - Isolation solenoid FGV4 SOV-V1G
- Start gas valve (FGV2)
- Valve control gas (FGV3)
- Anti-surge valve (bypass) by VBY solenoid valve (SOV-10).

6.6.2 PRIOR

Pre turbine control are basically three:

- Mode selection of the turbine start sequence
- elimination of triggers
- Startup permissions

The modes of the starting sequence of the turbine can only be changed by triggering the same condition and turbine are:

1. Automatic
2. Semi-Automatic
3. Stop (Off)




Figure 6-3 Operating Modes

Automatic startup executes the beginning of the startup sequence at the end, without need for intervention from the operator.

The Semi-Automatic Boot runs the startup sequence with two breaks for the launch sequence and the flame outlet of the turbine. This mode requires commands by the operator to perform the following sequence.

Off Mode (off) does not allow the turbine to start.

Triggers are eliminated, after resetting all alarms and after performing the RESET MASTER (main reset) control, using the push button only present in the screen page dedicated to turbine control, as shown in first figure of paragraph 6.6.

The turbine control needs a permission to be available at startup. Permission is the result of a set of conditions necessary to consider the subsidiary system ready to start. The state of the permission is available in the turbine control page, highlighted in the corresponding screen page in the section 6.6.3.1 (Figure 6-6).



The table below shows all the necessary conditions for the start permission. The list is split into two blocks as shown on the next page:

Block permissions 1: description	Bypass
Automatic auxiliary oil pump (PMOA)	NO
Automatic emergency oil pump (PMOE)	NO
PT 9G> State BAS	NO
Gas heater according	NO
Ready to launch engine start	NO
*****	***
*****	***
Fan 1 oil cooling (E1) in automatic	YES
Oil cooling fan 2 (E2) Automatic	YES
Automatic management candles	NO
PT 1> State BAS	NO

Table 6-1 First block permissions

Block permissions 2: description	Bypass
*****	**
*****	**
Overspeed (SOV-V2) Automatic	NO
*****	**
*****	**
Anti-surge valve open	NO
PT 7> Status BAS	NO
Closed gas control valve	NO
Speed <DOWN State	YES
Automatic engine start	NO
Automatic turbine inlet oil temperature control	NO
Inhibition turbine startup after shutdown	NO

Table 6-2 Second permissions block

For completeness we must add that during the interview, not enabled the operator user, it is possible to avoid certain permissions, and some not, as indicated in the table indication.

If all listed states are active, permission is available (green led); While some states are avoided (bypass), but permission is still available (green led), the derivation is highlighted with all avoided by (yellow) alarm. The following figures show the situation just described.




Figure 6-4 Signalling permissions




Figure 6-5 Permissions window

6.6.3 OPERATION

The operation of the turbine control is mainly divided into two phases shown in the screen-pages dedicated to:

- Control: turbine takes care of startup / shutdown of the turbine and monitoring of the main variables involved in the regulation and can be further subdivided as follows:
 - a. Reset triggers
 - b. Starting the turbine
 - c. Control and safety devices
 - d. Planned shutdown
 - e. Surveillance

In the following paragraphs are reported in the order that we will describe the turbine control functions.

6.6.3.1 RESET OF TRIGGERS

The triggers reset operation is a delicate and main phase to turn the turbine, therefore we provide a careful description below.




Figure 6-6 Reset triggers

1. Keep pressed the alarm reset push button, to remove the current alarm.
2. Wait a few seconds to give time to the visual rearmament.
3. Keep pressed the push-button Master Reset to eliminate the triggers of the currently active turbine.
4. The led triggers turns green.
5. Repeat the first two points.
6. The led of the cumulative trigger turns green.
7. Manual reset of the launch engine, to perform on the local table.
8. Manual reset of the launch engine, to perform on the local table.
9. Repeat step 3 of the sequence.
10. The led permissions turns green, if there are no causes that inhibit the release.

6.6.3.2 STARTING THE TURBINE

The start sequence is divided into three sequences:

1. Start-up
2. Launching
3. Ignition

Note: the control takes into account the expected inconsistency between control and feedback, and in such a case by means of its activation is protected turbine.

The following illustrates the automatic sequence. The semi-automatic mode is strictly identical to the automatic mode, but requires an order by the operator to complete the sub-sequences listed above. If necessary we mentionera the command for the semi-automatic mode.

Once you meet the requirements shown in the above paragraph, the turbine is ready to start, unless it is stopped (off). The startup sequence begins with the start command by the operator.




Figure 6-6-7 Commands and signals starting phase

1. Start:

The current control instantly completes the start-up phase and automatically switches to that launch, while in semi-automatic mode the operator must press the push button to begin the sequence LAUNCH.

2. Launch:

The control automatically switches to the launch phase, while in semi-automatic mode the operator must press the push button to begin the sequence LAUNCH.

The launch sequence produces the following:

- a1. Launch engine ignition.
- a2. Increased launch engine speed reference
- a3. Stopping the VIR
- a4. Cleaning the turbine with compressor air.
- a5. Opening of the overspeed valve (SOV-FGV1) triggering HSP-6 (Table 6-3Point 13).
- a6. Opening the gas discharge valve (SOV-V2G).
- a7. Closing the gas discharge valve (SOV-V2G) Timed (Table 6-3Point 14).
- a8. Locking the launch engine speed reference.

3. Ignition:

The control automatically switches to the ignition phase, while in semi-automatic mode the operator must press the push button to start the sequence IGNITE.

The ignition sequence produces the following:

- i1. Lighting the candles combustion chambers (Table 6-3Point 15).
- i2. Opening the isolation valve (SOV-V1G) after an adjustable delay to the previous point (Table 6-3Point 16).
- i3. Taken flame if the median temperature of the combustion chamber (GT_PRV_COMBUSTOR) exceeds the flame confirmation threshold. It is important to note that the gas-start valve has a pre-calibrated mechanical opening to provide just the input gas with compressed air, ensuring the ignition of the combustion chambers (Table 6-3Point 17).
- i4. From that time, if a temperature of the combustion chamber (TE-1..6) Or the median falls below the flame failure threshold, the turbine is protected by a trigger (Table 6-3Point 18).
- i5. After the flame outlet, the launch engine speed reference starts to rise again.
- i6. Beginning of the control action on the valve start-up and regulation of the gas when the discharge pressure of the axial compressor (PT-6) meet the threshold (Table 6-3Point 19).
- i7. Launch engine shutdown. When the speed reaches the maximum speed threshold of the launch engine (Table 6-3Point 20), an adjustable timer is started, during which the starter motor speed is kept constant and equal to its maximum. At the end of the delay (Table 6-3Point 21) the starter motor is actually stopped. It is important to note that the turbine is already able to support themselves before this, but to avoid any thermal control problem and make the smoothest possible start is delayed engine shutdown to continue to benefit from its contribution.
- i8. Closing the anti-surge valve (SOV-10 bypass) obtained when a compressor discharge pressure threshold is reached or exceeded the corresponding speed threshold (Table 6-3Point 22).
- i9. Phase stabilization or preheating of the turbine, after reaching the reference speed and its maximum speed without load, now coincide with the timing of the turbine speed (Table 6-3Point 23).
- i10. At the end of the stabilization phase, the boot sequence is completed.

The figure below shows a generic temporal sequence of starting the turbine.



5. Limitation of acceleration (Table 6-3Point 9).

The always active safety in the control are:

1. Temperature combustion chambers: alarm and trip to the median of six temperatures (Table 6-3Point 2 and 3).
2. Exhaust turbine temperature: alarm and trip to the median of four temperatures (Table 6-3Point 4 and 5).
3. Temperature exhaust pipe - chimney: alarm and trip to the median of six temperatures (Table 6-3Point 7 and 8).
4. Lack of flame, valid for each sensor and the combustion chamber center (Table 6-3Point 18).
5. Electronic overspeed alarm and trip (Table 6-3Point 10 and 11).
6. Congruence control / valve response.
7. Disagreement redundant combustion temperature signals, exhaust turbine and exhaust pipe (Table 6-3Point 6)

6.6.3.4 STOP PLANNED

The shutdown sequence planned door to stop the turbine. It is activated by pressing the push button present in the control page and followed the steps described below.




Figure 6-6-9 Turbine stop command planned

1. Signaling controlled stop GCP which precedes the opening of 52G before the outbreak of "reverse power" (power back).
2. Control gradually decreases the load to acceleration of the opening by the GCP, the 52G switch.
3. Control decreases the speed up to the minimum operating speed (MOS).
4. The control maintains the speed for the MOS of the turbine cooling time.
5. At the end of the cooling control command to stop the turbine.

6.6.3.5 MONITORING OF MEASURES

In the turbine control of the page there are areas and tables showing substantial quantities for turbine management as shown in the figure below.




Figure 6-6-10 Boxes monitoring

On the main control is monitored temperatures:

- combustion chambers,
- turbine exhaust,
- exhaust pipe - chimney,

but also monitors the main values on control in the table on the left (0) And vibration (0). In the center of the page there is the table of starts (6.6.3.6.2) And below, in addition to push buttons with the main controls of the turbine, the anti-surge valve (bypass) with its state is displayed.



Figure 6-6-11 Parameter Description

Beside the table also indicates the metal temperatures of the thrust bearing.



6.6.3.5.1 TABLE STARTS

The table starts indicates the number of starts as well as non-successful starts.

Set to start it indicates the hours of operation of the turbine in the different possible configurations fuel, as gas, liquid and crude oil. The operation is divided into normal and crest.

START-UP PANEL	
Quantité de Démarrages	16
Quantité de Démarrages Manque	3
Heures d funct. Nominal GAZ	63
Heures d funct. d Pointe GAS	0
Heures d funct. Nominal LIQUID	0
Heures d funct. de Pointe LIQUID	0
Heures d funct. Crude OIL	0
Heures d funct. Équivalente	223

Figure 6-6-12 Table start

Among the parameters, the most important parameter is the equivalent operating hours, fundamental for the maintenance scheduling of the turbine.

6.6.3.6 PARAMETERS CONFIGURATION CONTROL

The main parameters of turbine control configuration are listed in the table below:

	Description	threshold	unit
1.	Combustion chamber temperatures: Reference	630	° C
2.	Temperatures combustion chamber: alarm (start / load)	600/855	° C
3.	Temperatures combustion chamber: Trigger (start / load)	700/950	° C
4.	Turbine exhaust temperatures: Alarm	450	° C
5.	Turbine exhaust temperatures: Trigger	460	° C
6.	Disagreement redundant signals (start / load)	80/120	° C
7.	Temperatures exhaust pipe: Alarm	430	° C
8.	Temperatures exhaust pipe: Trigger	440	° C
9.	Acceleration: Reference	10	turn / s
10.	Overspeed: Alarm	3200	rev / min
11.	Overspeed: Trigger	3250	rev / min
12.	Threshold VIR stop	300	rev / min
13.	Threshold HSP-6 indication *: PT-6 Pressure speed	~ 0045 600 ~	barg rev / min



14.	Relief valve delay SOV-V2G	10	dry
15.	Delay of TR1..3 spark plug	3	min
16.	Delay opening isolation valve SOV-V1G-	20	dry
17.	Flame temperature confirmation	250	° C
18.	Release temperatures flame failure	200	° C
19.	Threshold control gas valves, axial compressor discharge pressure PT-6	0.22	barg
20.	Threshold motor stop launching turbine speed	1790	rev / min
21.	Delay launching engine stop	10	min
22.	Threshold bypass closure: PT-6 Pressure speed	3.3 2700	barg rev / min
23.	Turbine preheating delay	2	min
24.	Speed limit during startup MOS	2940	rev / min
25.	Target speed	3000	rev / min

Table 6-3 Control parameters

* Note: The values are indicative because it is a pressure switch.

6.7 COMPRESSOR

The compressor is shown schematically in the document MD-222-09 page 3-4.

6.7.1 COMPONENTS

The components parts of the compressor, which also applies to the control system, is reported below:

- Transmitters:
 - LT-2101, Scrubber M2 level:
 - Low threshold Alarm @ (To be decided on site);
 - PT-4002A, Scrubber M2 pressure:



- Low threshold Alarm @ (To be decided on site);
- PT-4702, Scrubber M2 pressure:
 - Low Low threshold Alarm @ (To be decided on site);
- TE-3002, Scrubber M24 inlet temperature:
 - High threshold Alarm @ 80°C
- TE-3702, Scrubber M24 inlet temperature:
 - High High threshold Alarm @ 90°C
- LT-2101, Scrubber M24 level:
 - Low threshold Alarm @ (To be decided on site);
- LT-2820, OIL BUFFER TANK level:
 - High threshold Alarm @ (To be decided on site);
 - High High threshold Alarm @ (To be decided on site);
 - Low Low threshold Alarm @ (To be decided on site);
 - Low threshold Alarm @ (To be decided on site);
- PDT-41021, SEAL OIL inlet delivery line differential pressure:
 - Low threshold Alarm @ (To be decided on site);
- PT-4820, SEAL OIL inlet supply line pressure (From lube oil):
 - Low Low threshold Alarm @ (To be decided on site);

6.7.2 PRIOR


All equipment listed below should be left in automatic mode:

- RPM-3C, Seal oil emergency pump:
- RPM-3B, Seal oil auxiliary pump:
- RPM-3A, Seal oil main pump:
- LCV-2820
- TM-2-E
- TM-2-F
- ROV-5011
- ROV-5004
- LCV-2104
- ROV-5010
- ROV-5005
- ROV-5008
- FCV-1003
- ROV-5006
- ROV-5003
- LCV-2102
- SOV-1001A
- FCV-1001A
- ROV-5009



6.7.3 OPERATION

Make sure all Antisurge parameters settings are inserted and antisurge valve is in AUTO by relevant indicator on Antisurge dashboard page:



When you ready to export gas push relevant push button on Antisurge dashboard page:



7 FUNCTIONAL DESCRIPTION AUXILIARY COMPONENTS

7.1 ELECTRICAL EQUIPMENT

7.1.1 AUXILIARY OIL PUMP: PMOA

It has access to the pump controls with the corresponding section of the screen page "LUBRICATING OIL TURBINE SYSTEM AND MOUTH". The graphic object is identified by the abbreviation "PMOA".




OBJECT PMOA

It can be run in manual and automatic modes.


7.1.1.1 MANAGEMENT MANUAL

If one selects the "Operator" the pump can be started and stopped manually, regardless of installation conditions.



7.1.1.2 AUTOMATIC MANAGEMENT

If one selects the "Program" the pump is managed automatically, based on the installation conditions.



The following conditions cause the automatic start of the pump:

- Low pressure PT_3;


The following conditions cause the automatic pump stop:

- High pressure PT_3;

7.1.1.3 PRESENCE OF PRIORITY CONTROL (OVERRIDE)

Regardless of the mode "Auto" or "Manual" in the presence of an override the pump is off. For PMOA causes override are:

Open main switch: MS_IN001_FINE_IN_ALM;



Presence Override (Override)

7.1.1.4 FAULTS

The following causes may cause the non-starting the pump:

1. Non-activated Drawer:
 - Display:



- Alarm "Not Start" PMOA_ALM1_ALM
- Action:
 - Enable and reset the MCC drawer 4
- 2. Intervention of electrical protection:
 - Display:
 - Alarm "Not Start" PMOA_ALM1_ALM
 - Action:
 - Check the cause and reset the MCC drawer 4
- 3. API protection for Intervention:
 - Display:
 - Alarm "Non-stop": PMOA_ALM2_ALM
 - Action:
 - Check the cause and reset the MCC drawer 4
- 4. Open main switch:
 - Display:
 - Showing override (override) on screen page
 - Alarm "open Main switch" MS_IN001_FINE_IN_ALM
 - Action:
 - Check the cause and closing the main switch
- 5. Intervention Fire detection system and gas:
 - Display:
 - View "Trigger system for detecting fires and gas": FG_ALM_GEN_ALM_FINE_IN_ALM
 - Alarm "open Main switch" MS_IN001_FINE_IN_ALM
 - Alarm "Not Start" PMOA_ALM1_ALM
 - Action:
 - Wait until the intervention of the detection system Fire & Gas
 - Turn off main switch



7.1.2 OIL PUMP RELIEF: PMOE

It has access to the pump controls with the corresponding section in the screen page "SYSTEM LUBRICATING OIL AND MOUTH TURBINE".

The corresponding graphic object is identified by the initials "PMOE."



PMOE OBJECT

It can be run in manual and automatic modes.

7.1.2.1 MANAGEMENT MANUAL

If you select the "Operator" mode the pump can be started and stopped manually, regardless of installation conditions.



7.1.2.2 AUTOMATIC MANAGEMENT

If you select the "Program" mode the pump is managed automatically, based on the installation conditions.



The following conditions cause the automatic start of the pump:

- Very low pressure PT_1;

The following conditions cause the automatic pump stop:

- NO PT_1 low pressure;
-

7.1.2.3 PRESENCE OF PRIORITY CONTROL (OVERRIDE)

The PMOE pump provides no way of Override.

7.1.2.4 FAULTS

The following causes may cause the non-starting the pump:

- 1 Intervention of electrical protection (HQ-DC):
 - Signalling:
 - Switch open alarm HQ-DC MS_IN043_FINE_IN_ALM
 - Alarm "Not Start" PMOE_ALM1_ALM
 - Action:
 - Check the cause of the intervention and close HQ-DC
- 2 Anomaly starter CC:
 - Signalling:
 - Alarm Fault start system KF-GTH75: MS_IN133_FINE_IN_ALM
 - Alarm "Not Start" PMOE_ALM1_ALM
 - Action:
 - Check the cause and reset the alarm "Fault start system KF-GTH75"
- 3 Intervention Fire detection system and gas:
 - Signalling:
 - View "Trigger system for detecting fires and gas": FG_ALM_GEN_ALM_FINE_IN_ALM
 - Alarm "Not Start" PMOE_ALM1_ALM
 - Action:
 - Wait until the intervention of the detection system Fire & Gas



7.1.3 OIL COOLER: EH1

It has access to the radiator controls by the relevant section in the screen page "SYSTEM LUBRICATING OIL AND MOUTH TURBINE". The corresponding graphic object is identified by the abbreviation "EH1."



EH1 OBJECT

It can be run in manual and automatic modes.


7.1.3.1 MANAGEMENT MANUAL

If you select the "Operator" mode, the heater can be started and stopped manually, regardless of installation conditions.



7.1.3.2 AUTOMATIC MANAGEMENT

If one selects the "Program" the radiator is handled automatically, based on the installation conditions.



The following conditions cause the automatic start of the radiator:

- Low temperature TE_205 NOT Intervention LSL_10;


The following conditions cause the automatic shutdown of the radiator:

- Low temperature or NO response TE_205 LSL_10;

7.1.3.3 PRESENCE OF PRIORITY CONTROL (OVERRIDE)

Regardless of the mode "Auto" or "Manual" in the presence of an override control the heater is turned off. For EH1 causes override are:

- Open main switch: MS_IN001_FINE_IN_ALM;
- Very low pressure PT_1;
- LSL_10 response;



Presence Override (Override)

7.1.3.4 FAULTS

The following causes may cause the non-start of the radiator:



1. Non-activated Drawer:
 - Signalling:
 - Alarm "Not Start" EH1_ALM1_ALM
 - Action:
 - Enable and reset the MCC drawer 3
2. Intervention of electrical protection:
 - Signalling:
 - Alarm "Not Start" EH1_ALM1_ALM
 - Action:
 - Check the cause and reset the MCC drawer 3
3. API protection for Intervention:
 - Signalling:
 - Alarm "Non-stop" EH1_ALM2_ALM
 - Action:
 - Check the cause and reset the MCC drawer 3
4. Open main switch:
 - Signalling:
 - Showing override (override) on screen page
 - Alarm "open Main switch" MS_IN001_FINE_IN_ALM
 - Action:
 - Check the cause and closing the main switch
5. Intervention Fire detection system and gas:
 - Signalling:
 - Display "Trigger system for detecting fires and Gas": FG_ALM_GEN_ALM_FINE_IN_ALM
 - Alarm "open Main switch" MS_IN001_FINE_IN_ALM
 - Alarm "Not Start" EH1_ALM1_ALM
 - Action:
 - Wait until the intervention of the detection system Fire & Gas
 - Turn off main switch



7.1.4 EXTRACTION OF OIL FUMES: OIL STEAM EXTR

It has access to the extractor orders the corresponding section in the screen page "LUBRICATING OIL TURBINE SYSTEM AND MOUTH". The corresponding graphic object is identified by the acronym "OIL VAPOUR EXTR".



OBJECT OIL EXTR VAPOEUR

It can be operated in manual and automatic modes.


7.1.4.1 MANAGEMENT MANUAL

If you select the "Operator" extractor mode can be started and stopped manually, regardless of installation conditions.



7.1.4.2 AUTOMATIC MANAGEMENT

If you select the mode "Programme" extractor is handled automatically, based on the installation conditions.



The following conditions cause the automatic start of the extractor:

- Virateur running or speed of the turbine is not zero;

The following conditions cause the automatic shutdown of the extractor:

- None of the conditions that cause automatic operation;

7.1.4.3 PRESENCE OF PRIORITY CONTROL (OVERRIDE)

Regardless of the mode "Auto" or "Manual" in the presence of an override control the extractor is turned off. For "EXTR OIL VAPOR" the causes of priority order are:

- Open main switch: MS_IN001_FINE_IN_ALM;



Presence Override (Override)



7.1.4.4 FAULTS

The following causes may cause the non-start of the extractor:

1. Non-activated Drawer:
 - Signalling:
 - Alarm "Not Start" PRESS_ALM1_ALM
 - Action:
 - Enable and reset the MCC drawer 11
2. Intervention of electrical protection:
 - Signalling:
 - Alarm "Not Start" PRESS_ALM1_ALM
 - Action:
 - Check the cause and reset the MCC drawer 11
3. API protection for Intervention:
 - Signalling:
 - Alarm "Non-stop": PRESS_ALM1_ALM
 - Action:
 - Check the cause and reset the MCC drawer 11
4. Main switch
5. Display open:
 - Signalling:
 - Override on screen page
 - Alarm "open Main switch" MS_IN001_FINE_IN_ALM
 - Action:
 - Check the cause and closing the main switch
6. Intervention Fire detection system and gas:
 - Signalling:
 - View "Trigger system for detecting fires and gas": FG_ALM_GEN_ALM_FINE_IN_ALM
 - Alarm "open Main switch"
 - Alarm "open Main switch" MS_IN001_FINE_IN_ALM
 - Action:
 - Wait until the intervention of the detection system Fire & Gas
 - Turn off main switch



7.1.5 FAN OIL COOLER: T2AB

Fans commands you have access to the relevant section in the screen page "LUBRICATING OIL TURBINE SYSTEM AND MOUTH".

The electric fan control is performed by MCC drawer and a case containing an inverter. The graphic object is identified by the corresponding "E1" acronym for MCC drawer, and "E1 INV" to the inverter.



E1 Purpose



E1 INV OBJECT

It can be operated in manual and automatic modes.

7.1.5.1 MANAGEMENT MANUAL OBJECT E1

If you select the "Operator" mode the fan can be started and stopped manually, regardless of installation conditions.



7.1.5.2 AUTOMATIC MANAGEMENT OBJECT E1

If you select the "Program" mode the fan is automatically controlled, based on the installation conditions.



The following condition causes the automatic start of the fan:

- ICT temperature controller output 17A of the upper threshold High Temp. matching;



The following conditions cause the automatic shutdown of the fan:

- ICT temperature controller output 17A below the threshold of low temp. matching;




7.1.5.3 PRESENCE OF PRIORITY CONTROL (OVERRIDE)

No override mode is provided.


7.1.5.4 MANAGEMENT MANUAL OBJECT "E1 INV"

If the "Operator" mode is selected in the graphic object "AO TO INVERTER E1" fan speed can be adjusted manually, regardless of installation conditions.



7.1.5.5 AUTOMATIC MANAGEMENT OF THE OBJECT "E1 INV"

If you select the "Operator" mode in the graphic object "AO TO INVERTER E1" fan speed tracks the value requested by the PIC 17A.




7.1.5.6 FAULTS

The following causes may cause the non-fan start:

1. Non-activated Drawer:
 - Signalling:
 - Alarm "Not Start" E1_ALM1_ALM
 - Action:
 - Enable and reset the MCC drawer 1
2. Intervention electrical protection MCC drawer 1:
 - Signalling:
 - Alarm "Not Start" E1_ALM1_ALM
 - Action:
 - Check the cause and reset the MCC drawer 1
3. UPS not available Table E1:
 - Signalling:
 - Alarm "Not Start" E1_ALM1_ALM
 - Action:
 - Reset the MCC drawer 1
4. Intervention Table E1 electrical inverter protections:
 - Signalling:
 - Alarm "Not Start" E1_ALM1_ALM
 - Action:
 - Check cause and reset Table E1 UPS
5. Intervention of specific protections E1 UPS:
 - Signalling:



- Display on screen page E1 INV object colored yellow
- Alarm not available Inverter: E1_INV_FAULT_FINE_IN_ALM
- Actions:
 - Check cause
 - Rearm E1 UPS by pressing the push button corresponding



- Feed Table E2 UPS
- 6. API protection for Intervention:
 - Signalling:
 - Alarm "Non-stop" E1_ALM2_ALM
 - Action:
 - Check the cause and reset the MCC drawer 1
- 7. Open main switch:
 - Signalling:
 - Showing override (override) on screen page
 - Alarm "open Main switch" MS_IN001_FINE_IN_ALM
 - Action:
 - Check the cause and closing the main switch
- 8. Intervention Fire detection system and gas:
 - Signalling:
 - View "Trigger system for detecting fires and gas": FG_ALM_GEN_ALM_FINE_IN_ALM
 - Alarm "open Main switch" MS_IN001_FINE_IN_ALM
 - Alarm "Not Start" E1_ALM1_ALM
 - Action:
 - Wait until the intervention of the detection system Fire & Gas
 - Turn off main switch



7.1.6 FAN OIL COOLER: T2BB

Fans commands you have access to the relevant section in the screen page "LUBRICATING OIL TURBINE SYSTEM AND MOUTH".

The electric fan control is performed by MCC drawer and a case containing an inverter. The graphic object is identified by the corresponding "E2" acronym for MCC drawer, and "E2 INV" to the inverter.



OBJECT E2




E2 INV OBJECT

It can be operated in manual and automatic modes.

7.1.6.1 MANAGEMENT MANUAL OBJECT E2

If you select the "Operator" mode the fan can be started and stopped manually, regardless of installation conditions.




7.1.6.2 AUTOMATIC MANAGEMENT OBJECT E2

If you select the "Program" mode the fan is automatically controlled, based on the installation conditions.




The following condition causes the automatic start of the fan:

- ICT temperature controller output 17A of the upper threshold High Temp. matching;



The following conditions provocano automatic shutdown della fan:

- ICT temperature controller output 17A below the threshold of low temp. matching;




7.1.6.3 PRESENCE OF PRIORITY CONTROL (OVERRIDE)

No override mode is provided.


7.1.6.4 MANAGEMENT MANUAL OBJECT "E2 INV"

If the "Operator" mode is selected in the graphic object "AO TO INVERTER E1" fan speed can be adjusted manually, regardless of installation conditions.



7.1.6.5 AUTOMATIC MANAGEMENT OF THE OBJECT "E2 INV"

If you select the "operator" mode in the graphic object "AO TO INVERTER E1" fan speed tracks the value requested by the PIC 17A.



7.1.6.6 FAULTS

The following causes may cause the non-fan start:

1. Non-activated Drawer:
 - Signalling:
 - Alarm "Not Start" E2_ALM1_ALM
 - Action:
 - Enable and reset the MCC drawer 1
2. Intervention electrical protection MCC drawer 1:
 - Signalling:
 - Alarm "Not Start" E2_ALM1_ALM
 - Action:
 - Check the cause and reset the MCC drawer 1
3. UPS not available Table E2:
 - Signalling:
 - Alarm "Not Start" E2_ALM1_ALM
 - Action:
 - Reset the MCC drawer 1
4. Intervention Table E2 electrical inverter protections:
 - Signalling:
 - Alarm "Not Start" E2_ALM1_ALM
 - Action:
 - Check cause and reset Table E2 UPS
5. Intervention of specific protections UPS E2:
 - Signalling:



- Display on screen page E2 INV object colored yellow
- Alarm not available Inverter: E2_INV_FAULT_FINE_IN_ALM
- Actions:
 - Check cause
 - Reset E2 UPS by pressing the push button corresponding



Push Button Reset

- Feed Table E2 UPS
6. API protection for Intervention:
- Signalling:
 - Alarm "Non-stop": E2_ALM2_ALM
 - Action:
 - Check the cause and reset the MCC drawer 1
7. Open main switch:
- Signalling:
 - Showing override (override) on screen page
 - Alarm "open Main switch" MS_IN001_FINE_IN_ALM
 - Action:
 - Check the cause and closing the main switch
8. Intervention Fire detection system and gas:
- Signalling:
 - View "Trigger system for detecting fires and gas": FG_ALM_GEN_ALM_FINE_IN_ALM
 - Alarm "open Main switch" MS_IN001_FINE_IN_ALM
 - Alarm "Not Start" E2_ALM1_ALM
 - Action:
 - Wait until the intervention of the detection system Fire & Gas
 - Turn off main switch



7.1.7 TURNING GEAR: VIR

Tacking the commands you have access to the relevant section in the screen page "GEAR BOX WARDROBE."
The corresponding graphic object is identified by the abbreviation "VIR."



VIR OBJECT

It can be operated in manual and automatic modes.

7.1.7.1 MANAGEMENT MANUAL

If you select the "Operator" mode the understeer can be started and stopped manually, regardless of installation conditions.



7.1.7.2 AUTOMATIC MANAGEMENT

If you select the "Program" mode the turning gear is handled automatically, based on the installation conditions.



The following conditions cause the automatic start of tacking:

- Very low pressure PT_1;

The following conditions cause the automatic shutdown of tacking:

- NO PT_1 low pressure;

7.1.7.3 PRESENCE OF PRIORITY CONTROL (OVERRIDE)

VIR provides no way of Override.

7.1.7.4 FAULTS

The following causes may cause the non-start tacking:

1. Intervention of electrical protection (HQ-DC):
 - Signalling:
 - Switch open alarm HQ-DC MS_IN043_FINE_IN_ALM
 - Alarm "Not Start" VIR_ALM1_ALM
 - Action:
 - Check the cause of the intervention and close HQ-DC
2. Anomaly starter CC:
 - Signalling:
 - Alarm Fault start system KF-GTH50: MS_IN143_FINE_IN_ALM
 - Alarm "Not Start" VIR_ALM1_ALM
 - Action:
 - Check the cause and reset the alarm "Malfunction KF-GTH50"
3. Intervention Fire detection system and gas:
 - Signalling:
 - View "Trigger system for detecting fires and gas": FG_ALM_GEN_ALM_FINE_IN_ALM
 - Alarm "Not Start" VIR_ALM1_ALM
 - Action:
 - Wait until the intervention of the detection system Fire & Gas



7.1.8 AIR TREATMENT SYSTEM INSTRUMENTS: DRY-COOLER

It has access to the controls of the air treatment system instruments by the relevant section in the screen page "AIR TURBINE INSTRUMENTATION". The corresponding graphic object is identified by the abbreviation "DRY".




OBJECT DRY

It can only be managed manually.

7.1.8.1 MANAGEMENT MANUAL

The air drying system must be started manually using the selector in the corresponding MCC drawer 15. The video interface only allows to stop the device, by using the disconnect coil: after operation the drawer must be manually reset.



7.1.8.2 FAULTS

The following causes may cause the non-starting the dryer:

1. Non-powered equipment:
 - o Signalling:
 - Feedback walk NOT present;
 - o Action:
 - Powering the device via the switch on the MCC drawer 15
2. Non-activated Drawer:
 - o Signalling:
 - Feedback walk NOT present;
 - o Action:
 - Activate the drawer and power the unit using the switch on the MCC drawer 15



3. Intervention of electrical protection:

- Signalling:
 - Feedback walk NOT present;
- Action:
 - Check the cause and power the unit using the switch on the MCC drawer 15

4. Open main switch:

- Signalling:
 - Feedback walk NOT present;
 - Alarm "open Main switch" MS_IN001_FINE_IN_ALM
- Action:
 - Check the cause and closing the main switch


5. Intervention Fire detection system and gas:

- Signalling:
 - View "Trigger system for detecting fires and gas": FG_ALM_GEN_ALM_FINE_IN_ALM
 - Alarm "open Main switch" MS_IN001_FINE_IN_ALM
 - Feedback walk NOT present;
- Action:
 - Wait until the intervention of the detection system Fire & Gas
 - Turn off main switch



7.1.9 EXTRACTION OF SAND: S-EM1

It controls access to the extractor by the corresponding section in the screen page "PAGE CONTROL TURBINE". The corresponding graphic object is identified by the initials "S-EM1".



OBJECT S-EM1

It can be operated in manual and automatic modes.


7.1.9.1 MANAGEMENT MANUAL

If you select the "Operator" extractor mode can be started and stopped manually, regardless of installation conditions.



7.1.9.2 AUTOMATIC MANAGEMENT

If you select the mode "Programme" extractor is handled automatically, based on the installation conditions.



The following conditions cause the automatic start of the extractor:

- VIR on, or Turbine running;

The following conditions cause the automatic shutdown of the extractor:

- None of the conditions that cause automatic operation;

7.1.9.3 PRESENCE OF PRIORITY CONTROL (OVERRIDE)

Regardless of the mode "Auto" or "Manual" in the presence of an override the extractor is turned off. For S-EM1 causes override are:

Open main switch: MS_IN001_FINE_IN_ALM;



Presence Override (Override)

7.1.9.4 FAULTS

The following causes may cause the non-start of the extractor:

1. Non-activated Drawer:
 - o Signalling:



- Alarm "Not Start" S_EM1_ALM1_ALM
- Action:
 - Enable and reset the MCC drawer 17
- 2. Intervention of electrical protection:
 - Signalling:
 - Alarm "Not Start" S_EM1_ALM1_ALM
 - Action:
 - Check the cause and reset the MCC drawer 17
- 3. API protection for Intervention:
 - Signalling:
 - Alarm "Non-stop": S_EM1_ALM1_ALM
 - Action:
 - Check the cause and reset the MCC drawer 17
- 4. Open main switch:
 - Signalling:
 - Showing override (override) on screen page
 - Alarm "open Main switch" MS_IN001_FINE_IN_ALM
 - Action:
 - Check the cause and closing the main switch
- 5. Intervention Fire detection system and gas:
 - Signalling:
 - View "Trigger system for detecting fires and gas": FG_ALM_GEN_ALM_FINE_IN_ALM
 - Alarm "open Main switch" MS_IN001_FINE_IN_ALM
 - Alarm "Not Start" S_EM1_ALM1_ALM
 - Action:
 - Wait until the intervention of the detection system Fire & Gas
 - Turn off main switch



7.1.10 Cleaning system (PULSE JET): SQZ1

It has access to the commands of the cleaning system (Pulse Jet) by the corresponding section in the screen page "PAGE CONTROL TURBINE". The corresponding graphic object is identified by the abbreviation "SQZ1".




OBJECT SQZ1

It can be operated in manual and automatic modes.

7.1.10.1 MANAGEMENT MANUAL

If one selects the "Operator" the cleaning system (Pulse Jet) can be started and stopped manually, regardless of installation conditions.



7.1.10.2 AUTOMATIC MANAGEMENT

If one selects the "Program" the cleaning system (Pulse Jet) is handled automatically, based on the installation conditions.



The following conditions cause the automatic start of the cleaning system:

- PDH_32 response;
- Manual control by HSSEM_1 local operator;

The following conditions cause the automatic shutdown of the cleaning system:

- None of the conditions that cause automatic operation;

Automatic running condition lasts until at least one cycle of the cleaning system is completed.

7.1.10.3 PRESENCE OF PRIORITY CONTROL (OVERRIDE)

Regardless of the mode "Auto" or "Manual" in the presence of an override the cleaning system is off. For SQZ1 causes override are:

- Open main switch: MS_IN001_FINE_IN_ALM;
- S-EM1 not running;



Presence Override (Override)



7.1.10.4 FAULTS

The following causes may cause the non-starting the cleaning system (Pulse Jet):

1. Non-activated Drawer:
 - Signalling:
 - Alarm "Not Start" SQZ1_ALM1_ALM
 - Action:
 - Enable and reset the MCC drawer 19
2. Intervention of electrical protection:
 - Signalling:
 - Alarm "Not Start" SQZ1_ALM1_ALM
 - Action:
 - Check the cause and reset the MCC drawer 19
3. API protection for Intervention:
 - Signalling:
 - Alarm "Non-stop": SQZ1_ALM2_ALM
 - Action:
 - Check the cause and reset the MCC drawer 19
4. Open main switch:
 - Signalling:
 - Showing override (override) on screen page
 - Alarm "open Main switch" MS_IN001_FINE_IN_ALM
 - Action:
 - Check the cause and closing the main switch
5. Intervention Fire detection system and gas:
 - Signalling:
 - View "Trigger system for detecting fires and gas": FG_ALM_GEN_ALM_FINE_IN_ALM
 - Alarm "open Main switch" MS_IN001_FINE_IN_ALM
 - Alarm "Not Start" SQZ1_ALM1_ALM
 - Action:
 - Wait until the intervention of the detection system Fire & Gas
 - Turn off main switch



7.1.11 INTERSTAGE AIR COOLER FAN EL. MOTOR

It can be operated in manual and automatic modes.

7.1.11.1 MANAGEMENT MANUAL

If you select the "Operator" mode the fan can be started and stopped manually, regardless of installation conditions.



7.1.11.2 AUTOMATIC MANAGEMENT

If you select the "Program" mode the fan is automatically controlled, based on the installation conditions.



The following conditions cause the automatic start of the fan:
Turbine ready to service;



- High threshold reached for TE_3002;
- Low threshold reached for TE_3002;

The following conditions cause the automatic shutdown of the fan:

- None of the conditions that cause automatic operation;

7.1.11.3 FAULTS

The following causes may cause the cooler start:

1. Non-activated Drawer:
 - Signalling:
 - Alarm "Not Start"
 - Action:
 - Enable and reset the MCC drawer 5
1. Intervention of electrical protection:
 - Signalling:
 - Alarm "Not Start"
 - Action:
 - Check the cause and reset the MCC drawer 5
2. API protection for Intervention:
 - Signalling:
 - Alarm "Non-stop"
 - Action:
 - Check the cause and reset the MCC drawer 5
3. Open main switch:
 - Signalling:
 - Showing override (override) on screen page
 - Alarm "open Main switch"
 - Action:
 - Check the cause and closing the main switch
4. Intervention Fire detection system and gas:
 - Signalling:
 - View "from Trigger Fires and Gas detection system"
 - Alarm "open Main switch"
 - Alarm "Not Start"
 - Action:
 - Wait until the intervention of the detection system Fire & Gas
 - Turn off main switch



7.1.12 COMPRESSOR SEAL/LUBE OIL MAIN & AUX EL. MOTOR

It can be operated in manual and automatic modes.

7.1.12.1 MANAGEMENT MANUAL

If you select the "Operator" mode the pump can be started and stopped manually, regardless of installation conditions.



7.1.12.2 AUTOMATIC MANAGEMENT

If you select the "Program" mode the pump is handled automatically, based on the installation conditions.



The following conditions cause the automatic start of the pump:



- Speed > 0;
- PT_4308 Low Low threshold
- PT_4308 Low threshold

7.1.12.3 FAULTS

The following causes may cause the non-starting of the pump:

1. Non-activated Drawer:
 - Signalling:
 - Alarm "Not Start"
 - Action:
 - Enable and reset the MCC drawer 6
2. Intervention of electrical protection:
 - Signalling:
 - Alarm "Not Start"
 - Action:
 - Check the cause and reset the MCC drawer 6
3. API protection for Intervention:
 - Signalling:
 - Alarm "Non-stop"
 - Action:
 - Check the cause and reset the MCC drawer 6
4. Open main switch:
 - Signalling:
 - Showing override (override) on screen page
 - Alarm "open Main switch"
 - Action:
 - Check the cause and closing the main switch
5. Intervention Fire detection system and gas:
 - Signalling:
 - View "from Trigger Fires and Gas detection system"
 - Alarm "open Main switch"
 - Alarm "Not Start"
 - Action:
 - Wait until the intervention of the detection system Fire & Gas
 - Turn off main switch



7.1.13 COMPRESSOR SEAL/LUBE OIL EMERGENCY EL. MOTOR

It can be operated in manual and automatic modes.

7.1.13.1 MANAGEMENT MANUAL

If you select the "Operator" mode the pump can be started and stopped manually, regardless of installation conditions.



7.1.13.2 AUTOMATIC MANAGEMENT

If you select the "Program" mode the pump is handled automatically, based on the installation conditions.



The following conditions (together) cause the automatic start of the pump:



- LY_2820 STS_L or PT_1_STS_LL;
- Not PT_03_L;
- PT_4305 > 0.2

7.1.13.3 FAULTS

The following causes may cause the non-starting of the pump:

1. Non-activated Drawer:
 - Signalling:
 - Alarm "Not Start"
 - Action:
 - Enable and reset the MCC drawer 7
2. Intervention of electrical protection:
 - Signalling:
 - Alarm "Not Start"
 - Action:
 - Check the cause and reset the MCC drawer 7
3. API protection for Intervention:
 - Signalling:
 - Alarm "Non-stop"
 - Action:
 - Check the cause and reset the MCC drawer 7
4. Open main switch:
 - Signalling:
 - Showing override (override) on screen page
 - Alarm "open Main switch"
 - Action:
 - Check the cause and closing the main switch
5. Intervention Fire detection system and gas:
 - Signalling:
 - View "from Trigger Fires and Gas detection system"
 - Alarm "open Main switch"
 - Alarm "Not Start"
 - Action:
 - Wait until the intervention of the detection system Fire & Gas
 - Turn off main switch




7.2 VALVES

7.2.1 STOP GAS FUEL VALVE: FGV1

The valve is shown in the "GAS VALVE TURBINE POWER". Next to it we find the signs of the states of:

- ZSH-1 opening limit;
- ZSL-1 closing limit;



FGV1

The valve is controlled by means of air instruments, by the use of the solenoid valve "SOV-FGV-1" which is the "AIR TURBINE INSTRUMENTATION" page.



SOV-FGV-1

7.2.1.1 MANAGEMENT MANUAL

Manual management of the valve is not possible

7.2.1.2 AUTOMATIC MANAGEMENT

Automatic management of the valve is performed by the SOV-FGV-1.



Automatic opening:

- The automatic opening is described in the chapter 6.6.3.2



Automatic closing:

- When triggered.

7.2.1.3 PRESENCE OF PRIORITY CONTROL (OVERRIDE)

In the presence of the master control valve is closed. The causes of priority order are:
Triggering non-reset



Presence Override (Override)

7.2.1.4 FAULTS

The following causes can cause erroneous operation of the valve:

1. Blown fuse:
 - Signalling:
 - Alarm FGV_1_ALM1_ALM
 - Action:
 - Find the cause and replace the fuse
2. End of non-infringement opening race:
 - Signalling:
 - Alarm FGV_1_ALM1_ALM
 - Action:
 - Check the travel of the valve and the acquisition of the limit switch
3. Plea of infringement closing stroke:
 - Signalling:
 - Alarm FGV_1_ALM1_ALM
 - Action:
 - Check the travel of the valve and the acquisition of the limit switch
4. Simultaneous reading of the closing limit switches and openness:
 - Signalling:
 - Alarm FGV_1_ALM1_ALM
 - Action:
 - Check the position of limit switches and their acquisition



7.2.2 PURGE VALVE FUEL GAS: FGV6

The valve is shown in the "GAS VALVE TURBINE POWER". Next to it we find the signs of the states of:

- ZSH-6 opening limit;
- ZSL-6: closing limit;



FGV6

The valve is controlled by means of air instruments, the use of SOV-V2G solenoid valve, which is the "AIR TURBINE INSTRUMENTATION"



SOV-V2G

7.2.2.1 MANAGEMENT MANUAL

Manual management of the valve is not possible

7.2.2.2 AUTOMATIC MANAGEMENT

Automatic management of the valve is performed by the SOV-V2G.



Automatic opening:

- The automatic opening is described in the chapter 6.6.3.2

Automatic closing:

- When triggered.



7.2.2.3 PRESENCE OF PRIORITY CONTROL (OVERRIDE)

In the presence of the master control valve is closed. The causes of priority order are:

- Triggering non-reset



Presence Override (Override)

7.2.2.4 FAULTS

The following causes can cause erroneous operation of the valve:

1. Blown fuse:
 - Signalling:
 - Alarm FGV_6_ALM1_ALM
 - Action:
 - Find the cause and replace the fuse
2. End of non-infringement opening race:
 - Signalling:
 - Alarm FGV_6_ALM1_ALM
 - Action:
 - Check the travel of the valve and the acquisition of the limit switch
3. Plea of infringement closing stroke:
 - Signalling:
 - Alarm FGV_6_ALM1_ALM
 - Action:
 - Check the travel of the valve and the acquisition of the limit switch
4. Simultaneous reading of the closing limit switches and openness:
 - Signalling:
 - Alarm FGV_6_ALM1_ALM
 - Action:
 - Check the position of limit switches and their acquisition



7.2.3 ISOLATION VALVE FUEL GAS: FGV4

The valve is shown in the "GAS VALVE TURBINE POWER". On his side are the indications of the states of:

- ZSH-4: opening limit;
- ZSL-4: closing limit;



FGV4

The valve is controlled by means of air instruments, the use of SOV-V1G solenoid valve, which is the "AIR TURBINE INSTRUMENTATION"




SOV-V1G

7.2.3.1 MANAGEMENT MANUAL

Manual management of the valve is not possible

7.2.3.2 AUTOMATIC MANAGEMENT

Automatic management of the valve is performed by the SOV-V1G.



Automatic opening:

- The automatic opening is described in the chapter 6.6.3.2

Automatic closing:



- When triggered.

7.2.3.3 PRESENCE OF PRIORITY CONTROL (OVERRIDE)

In the presence of the master control valve is closed. The causes of priority order are:

- Triggering non-reset



Presence Override (Override)

7.2.3.4 FAULTS

The following causes can cause erroneous operation of the valve:

1. Blown fuse:
 - Signalling:
 - Alarm FGV_4_ALM1_ALM
 - Action:
 - Find the cause and replace the fuse
2. End of non-infringement opening race:
 - Signalling:
 - Alarm FGV_4_ALM1_ALM
 - Action:
 - Check the travel of the valve and the acquisition of the limit switch
3. Plea of infringement closing stroke:
 - Signalling:
 - Alarm FGV_4_ALM1_ALM
 - Action:
 - Check the travel of the valve and the acquisition of the limit switch
4. Simultaneous reading of the closing limit switches and openness:
 - Signalling:
 - Alarm FGV_4_ALM1_ALM
 - Action:
 - Check the position of limit switches and their acquisition


7.2.4 VALVE ANTISURGE: VBY

The valve is shown in the "AIR TURBINE INSTRUMENTATION". Next to it we find the signs of the states of:

- ZSH-VBY: opening limit;



- ZSL-VBY: closing limit;



VBY

The valve is controlled by means of air instruments, by the use of the SOV-10 solenoid valve, which is on the same page.



SOV-10

7.2.4.1 MANAGEMENT MANUAL

Manual management of the valve is not possible

7.2.4.2 AUTOMATIC MANAGEMENT

Automatic management of the valve is performed by the SOV-10.



Automatic opening:

- The automatic opening is described in the chapter 6.6.3.2

Automatic closing:

- In the absence of the opening control.

7.2.4.3 PRESENCE OF PRIORITY CONTROL (OVERRIDE)

For this valve management override is NOT intended.

7.2.4.4 FAULTS

The following causes can cause erroneous operation of the valve:

1. Blown fuse:
 - Signalling:



- Alarm SOV_10_EVB_ALM1_ALM
- Action:
 - Find the cause and replace the fuse
- 2. End of non-infringement opening race:
 - Signalling:
 - Alarm SOV_10_EVB_ALM1_ALM
 - Action:
 - Check the travel of the valve and the acquisition of the limit switch
- 3. Plea of infringement closing stroke:
 - Signalling:
 - Alarm SOV_10_EVB_ALM1_ALM
 - Action:
 - Check the travel of the valve and the acquisition of the limit switch
- 4. Simultaneous reading of the closing limit switches and openness:
 - Signalling:
 - Alarm SOV_10_EVB_ALM1_ALM
 - Action:
- 5. Check the position of limit switches and their acquisition

7.2.5 COMPRESSOR ANTISURGE VALVE

GENERAL FEATURES

For each compressor speed, it's possible to determine, on the plane SUCTION FLOW - COMPRESSION RATIO, a curve that describes all compressor operating points. Each obtained Curve meets its limits on the surge point, corresponding to the maximum polytrophic head. All Surge points, defined for different speeds represent the limit line, on the left of this line (called SURGE LIMIT LINE "SLL") the compressor operates in an unstable area.

The purpose of the "ANTISURGE CONTROL SYSTEM" is to avoid that the operating point "A" reaches the "SLL". To achieve this objective, it's defined, on the right of the "SLL", a Protection line where (point "B") the control system will operate opening the Antisurge valve. This line is called "SURGE CONTROL LINE" ("SCL"). The opening of the Antisurge valve Increases the suction flow moving the operating point along the speed characteristic curve, from The critical condition to the stable operating area (fig. 1).




Fig. 1



SYMBOLS LEGEND

N = compressor speed

K1, K2, K3, K4 = constant

Qs = volumetric flow

Hp = polytrophic head

Pd = discharge pressure

Ps = suction pressure

Z = compressibility factor

R = gas constant

T = gas absolute temperature

n = polytrophic head exponent

f3 = characteristic orifice constant

hs = dp across the orifice

ρs = suction gas density

PSA = absolute suction pressure

PDA = absolute discharge pressure

PSD = design suction pressure

K = deviation margin

S11 = surge limit line

Scl = surge control line

Pv = process variable (compressor operating point)

ANTISURGE CONTROL LAW

Considering a monostage centrifugal compressor, it is possible to verify the followings relations, varying the compressor speed, for each surge point:

$$(1) Q_s = K_1 * N$$

$$(2) H_p = K_2 * N^2$$

From (1) and (2) we obtain

$$(3) H_p = ZRT \left(\frac{n}{n-1} \right) \left[\frac{P_d \left(\frac{n-1}{n} \right)}{P_s} - 1 \right]$$

$$(4) H_p = K_2 \left(\frac{Q_s}{K_1} \right)^2 \quad \text{where} \quad \frac{K_2}{(K_1)^2} = K_3 = \text{constant} . \quad \text{So :} \quad H_p = K_3 (Q_s)^2$$

from (3) and (4) we obtain

$$(5) \quad ZRT \left(\frac{n}{n-1} \right) \left[\left(\frac{P_d}{P_s} \right)^{\left(\frac{n-1}{n} \right)} - 1 \right] = K_3 (Q_s)^2$$

If Q_s is measured through a calibrated orifice mounted on the compressor suction, we can express it related to the measured Δp

$$(6) \quad Q_s = \beta \sqrt{\frac{h_s}{\gamma_s}}$$

since $\gamma_s = \frac{P_s}{RZT}$ the (6) becomes $Q_s = \beta \sqrt{\frac{h_s * RZT}{P_s}}$ (7)

so we can describe the (5) as : $ZRT \left(\frac{n}{n-1} \right) \left[\left(\frac{P_d}{P_s} \right)^{\left(\frac{n-1}{n} \right)} - 1 \right] = K_3 \beta^2 \frac{h_s ZRT}{P_s}$

Simplifying ZRT in the expression, the obtained equation, that represents all the surge points in function of the orifice Δp ; we can demonstrate how the surge phenomenon is not influenced by the gas condition and composition.

$$(8) \quad h_s = \frac{P_s}{K_3 * \beta^2} \left(\frac{n}{n-1} \right) \left[\left(\frac{P_d}{P_s} \right)^{\left(\frac{n-1}{n} \right)} - 1 \right]$$

Moreover we can demonstrate that for small compression ratios and small n variations, the terms

$\frac{n}{n-1}$ e $\frac{n-1}{n}$ becomes roughly 1 and $\left(\frac{n}{n-1} \right) \left[\left(\frac{P_d}{P_s} \right)^{\left(\frac{n-1}{n} \right)} - 1 \right] \cong \frac{P_d}{P_s} - 1$; so the (8) becomes :

$$h_s = \frac{P_s}{K_3 * \beta^2} \left[\frac{P_d}{P_s} - 1 \right] \text{ where } \frac{1}{K_3 * \beta^2} = K_4 \text{ is a constant}$$

$$(9) \quad h_s = P_s * K_4 * \left[\frac{P_d}{P_s} - 1 \right] \Rightarrow \frac{h_s}{\left(\frac{P_d}{P_s} - 1 \right) * P_s * K_4} = 1$$

The equation (9) defines the "SLL" shape, on the plane of compression ratio (ρ) versus flow (Q), represented by a parabola which has the minimum located in $\rho = 1$ and $Q = 0$, Fig 1a .




Fig.1a





Fig.1b

The fig. 1a represents a theoretical performance characteristic for a single stage compressor (one impeller only) , while the Fig. 1b represents a typical characteristic for a multistage compressor . As we can see in the latter conditions the antisurge control line can not be realized utilizing a parabola without cutting a large zone of compressor operability .

In order to avoid this inconvenient, the Surge Control Line is calculated by a ten break lines function generator $f\left(\frac{P_d - P_s}{P_s}\right)$ that permits to realize the SLL and consequently the relevant SCL .

The SCL will be positioned at a pre-set percentage margin (K), to the right of the first one .



ANTISURGE CONTROL ALGORITHM

In order to meet the described requests, the control algorithm will be developed inside the controller is the follows :

$$\frac{h_s * \frac{P_{sd}}{P_s}}{f\left(\frac{P_d - P_s}{P_s}\right)} = K^2$$

Where :

hs = differential pressure on calibrated orifice mounted at the compressor suction (Eng. unit).

Pd = compressor discharge pressure (eng. unit).

Ps = compressor suction pressure (eng. unit).

Psd = compressor suction pressure at design conditions

The controller set-point is K^2 . It represents the deviation margin between "SLL" and "SCL". In the "Antisurge Control Line configuration sheet", the margin is expressed in percentage of flow. The algorithm takes in account the ΔP measured across the flow element (indicated by "hs") that is proportional to square suction flow ($h_s = Q^2$).

The controller algorithm compensates continuously the **hs** signal according to the suction pressure variation, taking in account the suction pressure measured and comparing it with the **design suction pressure**.



ANTISURGE CONTROLLER

The picture 2 shows the antisurge system diagram. With reference to the picture, the instruments range will be :

INSTRUMENT	MEASURED VARIABLE	RANGES
PT4200XA	SUCTION PRESSURE	0 – 300 Psig
PT4200XC	DISCHARGE PRESSURE	0 – 300 Psig
FIT4200X	ORIF. DIFFER. PRESSURE	0 – 2863 mmH ₂ O




Fig. 2



-Surge Limit Line

$$hs(sll) = \left(\frac{Q_{surge}}{Vol. flow.span@ref.cond.} \right)^2 Diff.press.span$$

-Surge Control Line

$$hs(scl) = hs(sll) \left[\frac{(Flow.mar. + 100)}{100} \right]^2$$

-Point R (real point)

This portion of values could be use for verify the operating point position during compressor running.

-Point N (normal point)

Represents the compressor operating point @ performance curve reference conditions

-FE design values

Values used for the design of flow element (data from FE calculation sheet) .

-FE values @ refer. condition

FE design values converted to the compressor reference condition.

-Surge value @ reference condition

Surge values expressed by volumetric suction flow and (Pd/Ps)-1 at compressor reference condition.

-hs_safe

Represent the antisurge controller setpoint in case of one or both pressure transmitters in fault.



ANTISURGE CONTROLLER OPERATION


Controller Operation; Cascade PI control by direct action with the following signals:

Inputs :

- a) Suction pressure (**PS**)
- b) Discharge Pressure (**PD**)
- c) Differential pressure on suction orifice "Suction Flow" (**hs**)
- d) "HIC" Antisurge valve manual opening/closing command.
- e) Safety Protection/Correction disabling.
- f) External protection (**EP**)
- g) "L3" (min. control speed) antisurge controller enable / disable.
- h) External Transient.
- i) PURGE command.
- j) Zero Speed.
- k) Solenoid Reset push button.
- l) External override controller.

Outputs :

- a) Antisurge valve control signal (**ASVC**)
- b) Solenoid Valve Command.
- c) Transmitter Failure indication.
- d) Safety Protection/Correction disabling indication.
- e) A/S Solenoid Valve de-energize indication.
- f) A/S Controller Manual Control indication.
- g) Feedback to external override controller.



a) Dead band function :

If the difference between parameter and margin is included between imposed value , the controller output does not change. This function permits to make the controller less sensitive to the noise of flow transmitter.

b) Transient Absorption :

If the measure decreases very fast , to anticipate the controller response , the controller set point is incremented by a fixed value.

When the condition resets , the set point return to the previous value following a pre-set ramp .



c) Safety Correction :

When the PV is lower of SLL plus 5% the antisurge controller output decreases following fixed steps in fixed time gaps until the PV goes back at a value higher than SLL plus 5% .

d) Safety Protection :

When the PV is lower of SLL plus 2% the antisurge controller output decreases following quick opening ramp until the PV goes back at the right of the safety correction line .

e) Rate limiter function :

It's used to avoid instability phenomenon on antisurge control introducing an output limit of variation, which can be set by the keyboard,.

f) Safety disabling function :

Allows disabling the safety protection and safety correction functions. Password protected.
A typical application of this function is the compressor surge points test, using the controller in manual mode.

g) Manual operation override function :

Allows the automatic disabling of manual control in case PV reaches the "Safety Correction" limit.

h) Controller Enabling/Disabling

When the controller is disabled the antisurge valve is forced to open position. Controller is generally enabled when min. control speed is reached.

i) Purge function :

Allows the complete closing of the antisurge valve when the compressor is stopped . Password protected.



8 SCHEDULES



8.1 DISPLAY HISTORICAL DATA (HISTORIAN VIEWER)

8.1.1 MAIN WINDOW OF THE HISTORIAN VIEWER

All functions are executed in this window (Figure 8-1)




Figure 8-1

Open New Trend (open new trend):

Click on the push button "New Trend" (new trend)  Trends to open a window and add the push button on the window bar.

New Open Table (open new table):

"New Table" (new table) , Application is not available in this project.

Open Trend RealTime (open real-time trend, only if the function is installed):

"Open RealTime Trend" , Application is not available in this project.

Auto Point Open Search (open automatic search points):

Click on the push button "Open Point Auto Search"  to open the search window automatically points (Point Auto Search).

Historian Viewer Setting (Setting the display of historical data):

Click on the push button "Setting"  to select from "User Setting" (user settings), "Function Level Setting" (function level setting) and "Database Connection Setting" (connection settings database) (Figure 8-2)




Figure 8-2

Change User (switch user):

Click on the pushbutton "Change User"  to change the current user.



Application Exit (exit the application):

Click on the push-button Release  Historian Viewer to exit.

Selecting windows to open:

Any trend window or table can be selected Historian Viewer using the Windows Menu (Figure 8-3)




Figure 8-3

Click with the left mouse button on the name of the desired window to open.

Click with the left mouse button on "Close All Windows" (close all windows) to close all open windows.

8.1.2 VIEW TREND (TREND DISPLAY)




Figure 8-4

Add New Plots (add new plots):

Click on the push button "Insert Point" (enter point)  (Figure 8-4) To open the window below that allows the user to select the data set table. (Figure 8-5).




Figure 8-5

Select Table Source in the first list box (listBox). In the second list box, the data points (data points) existing appear.

Select the item in the second list box (multiple selections Points allowed).

Select or délectionner the "From Data" filter (data) and "To Data" (up given).

Select the font color. (Only if the user selects only one item, the multiple points are colored randomly).

Click the acceptance push button  to draw the point.

Click on the push-button Release  to close the window.

Plots Delete (delete points):

Click on the push-button  to open the list of Points (fig.8).




Figure 8-6

Select the item in the listbox (multiple selections are allowed).

Click the acceptance push button  to delete the selected points of the trend.

Click on the push-button release  to close the window.

8.1.3 DISPLAY OF LEGENDS




Figure 8-7

A list of tracks (Plots) loaded is shown in the bottom of the trend, and allows the user to know the current path for each color, the name and the value by using the Cursor Mode (Cursor Mode).

Zoom Mode (Zoom mode)

Click on the pushbutton "Zoom enable mode" (activate zoom mode)  (Fig. 6) to zoom in on the plot area.

Scroll Mode (Scroll mode):

Click on the pushbutton "Scroll enable mode" (enable scroll mode)  (Fig. 6) to move the display patterns on the X axis and on the Y axis

Cursor mode (cursor mode):

Click on the pushbutton "Cursor enable mode" (enable cursor mode)  (Fig. 6) to review the plot area with a cross cursor and display the value of the X axis and Y axis. The slider allows the user to see the current value for each line of the trend by the display of captions (Fig.9).

Y Axis Reset (resetting Y axis status):

Click on the push button "reset Y" (resetting state Y)  to resize the Y axis according to the current points range.



Reset X Axis (resetting state X-axis):

Click on the push button "reset X" (resetting state X)  to resize the Y axis as the selected range of time from the scroll bar.

ScrollBar (scroll bar):

The scroll bar resizes the axis X visibility range of 1 minute minimum up to a maximum of 3 days.

Trend ConFiguretion (conFiguretion of the trend)

Click with the right mouse button on the pushbutton Plots Area (plot area) to open the popup to display menu with multiple functionality.

Configuring Points




Figure 8-8

Click "Select" (select) to set the current range of the Y axis with the selected item.

Click on "Visible" to enable or disable the visibility of the item selected.

Click "Change Line Color" (change the line color) to set a new color for the selected item.

Grid conFiguretion




Figure 8-9

Check "Enable Grid" (enable grid) to enable or disable the grid line on the Path area.

Click on "Set Y Axis Grid Division" (set Y axis grid division) to select the number of divisions of the grid on the Y axis

Click on "Set X Axis Grid Division" (set X axis grid division) to select the number of divisions of the grid on the X axis



Plot ConFiguretion




Figure 8-10

Click on "Auto Update Enable" (enable automatic updates) to activate the update in real time from the plots with the databases that do not have a maximum time limit.

Click "Only Real Plot Points" (draw only real points) to draw, for each plot, only Actual Points.

Click on "Set Line width" (adjust line width) to set the width of the line of the route.

Colour Settings




Figure 8-11

Click on "Background Color" (background color) to change the background color of the plot area.

Click on "Cursor Color" (cursor color) to change the color of the cross cursor.

8.1.4 SAVE / LOAD SETTING TRACKS

This tool allows the user to record Historian Viewer in a set of selected paths with a name. The entire conFiguretion is always available for reloading.



Figure 8-12

Save settings

Click on the recording-button  (Fig.14) to open a new dialog box in which the user can enter the name of the ConFiguretion and choose whether to share settings with other users or not (fig.15)



Figure 8-13

Enter the name, choose a private or public use and click on the Accept button  to save the conFiguretion (if the conFiguretion name already exists, the Utilisateur can overwrite or not).

Click on the push-button Release  to close the window without saving.

Load settings

Click on the loading pushbutton  (Fig.14) to open a new dialog box in which the user can select the settings to load. (Fig.16)




Figure 8-14

Select settings in the list on the left. Users may see an expected list of saved tracks to the right.

Click the acceptance push button  to open the selected settings.

Click on the push-button deletion  to delete the selected settings.

Click on the push-button Release  to close the window.

Save / load settings of the trend

This tool allows the recording in a Viewer Historian ConFiguretion tendency User (Grid Colors Grid Division etc.).



Figure 8-15

Save settings

Click on the recording-button  (Fig.17) to open a new dialog box in which the user can enter the name of the ConFiguretion and choose whether to share settings with other users or not (fig.18).



Figure 8-16

Enter the name, choose the private or public use and click on the Accept button  to save the configuration (if the configuration name already exists, the user can overwrite it or not).

Click on the push-button Release  to close the window without saving.

LOADING SETTINGS

Click on the loading pushbutton  (Fig.17) to open a new dialog box in which the user can select the settings to load.




Figure 8-17

Click the Default button  to load the default settings of Trend Setting selected for the current user (the default settings are automatically loaded to view the trend window).

Click the acceptance push button  to open the selected settings.

Click on the push-button deletion  to delete the selected settings.

Click on the push-button Release  to close the window.

8.1.4.1 CSV EXPORT TO DATA



Figure 8-18



Click on the push button "Export to CSV ..." (export to CSV) the Trend Menu (trend), enter a file name and click on the registration push button.

Exporting create a file with two columns for each route, one for the X axis and one for the Y axis

The Excel software to open a CSV file with more than 65000 rows.



VIEW TABLE (TABLES DISPLAY)

TimeStamp	Point Name	Point Description	Point Value
23/06/2005 11:32:23:320	FLOAT_12	IL SECONDO FLOAT	360
23/06/2005 11:32:23:320	FLOAT_14	IL QUARTO FLOAT	360
23/06/2005 11:32:23:320	FLOAT_16	IL SESTO FLOAT	360
23/06/2005 11:32:23:320	FLOAT_18	OTTAVO FLOAT	360
23/06/2005 11:32:23:320	FLOAT_20	IL DECIMO FLOAT	360
23/06/2005 11:32:23:310	FLOAT_20	IL DECIMO FLOAT	359
23/06/2005 11:32:23:310	FLOAT_1	IL PRIMO FLOAT	360
23/06/2005 11:32:23:310	FLOAT_3	IL TERZO FLOAT	360
23/06/2005 11:32:23:310	FLOAT_5	IL QUINTO FLOAT	360
23/06/2005 11:32:23:310	FLOAT_7	IL SETTIMO FLOAT	360
23/06/2005 11:32:23:310	FLOAT_9	IL NONO FLOAT	360
23/06/2005 11:32:23:300	FLOAT_7	IL SETTIMO FLOAT	359
23/06/2005 11:32:23:300	FLOAT_9	IL NONO FLOAT	359
23/06/2005 11:32:23:300	FLOAT_12	IL SECONDO FLOAT	359

Figure 8-19

OPEN TABLE OF EVENTS

Click Table loading the pushbutton  (Fig.20) to open the window below that allows the user to select data from a table of configured events.

InputPointSelection

DATA_CHANGE_REAL

From Data(dd/MM/yyyy HH:mm)
23/06/2005 10:41

To Data(dd/MM/yyyy HH:mm)
23/06/2005 11:41

Filter Point
<Tag>

Filter Description
<Description>

Figure 8-20

Select the Table of Events, edit selection filter with the time limit ("From data" and "To Data"), the limit points (use '*' as a special character) Description e limit (use '*' as a special character).

Click the acceptance push button  to load the table with the selected limits.

Click on the push-button Release  to close the window without loading the table.



EDIT THE FILTER SELECTION

Click on the Remove pushbutton  é ditation to open the dialog box of the filter table Current Events.




Figure 8-21

Edit the settings and click the accept button  to confirm the changes.

Click on the push-button Release  to close the window without editing the filter selection.

REFRAÎCHIR TABLE OF EVENTS

Click on the pushbutton Refraîchir  to reload the current table from the database.

Save / load settings table

This tool allows the viewer to record Historian in Table settings with a name User. All configurations are always available for reloading.

Click on the recording-button  (Fig.20) to open a new dialog box in which the user can enter the name of the Configuration and choose whether to share settings with other users is not.



Figure 8-22

Click on the loading pushbutton  (Fig.20) to open a new dialog box in which the user can select the settings to load.



Figure 8-23

Select Table Settings from the list e click the accept button  to load the selected table settings.

Click on the push-button deletion  to delete the selected settings.

Click on the push-button Release  to close the window without loading table settings.

Export to CSV data




Figure 8-24

Click on the push button "Export to CSV ..." (export to CSV) from the Table menu (Table), enter a file name and click on the registration push button.

The Excel does not open a CSV file with more than 65000 rows.

RESEARCH POINTS AUTOMATIC




Figure 8-25

Enter the Point Name (special character '*'), select a time range with "Data From" and "To Data", click the search-button  and wait for the result in the list boxes. (The search works only with Historian type tables. Select On Point Scan (multiple selection allowed) or On Change Table and click the "SHOW" push button for viewing.